

CREDENTIALS GUNLOCKE


ASSEMBLY INSTRUCTION MODULAR RETURN ASSEMBLY

GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS REPLACE EACH DRAWER IN IT'S ORIGINAL LOCATION TO MAINTAIN GAPS AND LOCK FUNCTION.
3. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.

THERE ARE (2) UNIQUE CHASSIS TYPES. EACH CHASSIS IS ILLUSTRATED.
THE WORKSURFACE ATTACHMENT TO EACH CHASSIS IS SIMILAR.

RETURN CHASSIS HARDWARE - WALL ACCESS PANEL



SA922-0001-35
PEDESTAL GANGING BRACKET



3500112000
SCR TP-A 10X5/8 PN PH


RETURN CHASSIS HARDWARE - FULL MODESTY PANEL



19928-0061-35
CAM FASTENER




19917-4488-36
CAM STUD




19896-0006-04
3/8X1-1/2 DOWEL

RETURN WORKSURFACE HARDWARE




19917-4327-36
SCR TP-AB 10X1-1/2 FT PH


1A. ASSEMBLE RETURN WITH WALL ACCESS PANEL




- 1 ATTACH BRACKETS TO PEDESTAL
AND WALL ACCESS PANEL



3500112000
SCR TP-A 10X5/8 PN PH




A ALIGN EDGES




C SECURE WITH SCREWS

B SLIDE BRACKET
ONTO PANELS


1B. ASSEMBLE RETURN WITH FULL FINISHED MOD PANEL



2 ASSEMBLE CHASSIS



ASSEMBLE WORKSURFACE - WALL ACCESS PANEL



ASSEMBLE WORKSURFACE - FULL FINISHED MODESTY PANEL

