


GUNLOCKE

GENERAL NOTES

1. GUNLOCKE ASSUMES NO RESPONSIBILITY FOR THE METHOD AND FASTENERS USED TO ATTACH BRACKET(S) TO THE WALL. IT IS THE RESPONSIBILITY OF THE INSTALLER / END USER TO DETERMINE THE APPROPRIATE METHOD OF ATTACHMENT BASED ON THE TYPE OF WALL MATERIAL AND OR STUDS AVAILABLE.

WALL MOUNT HARDWARE





WALL MOUNT BRACKET(S)

OVERHEAD HARDWARE




LED LIGHT

2X CV902-0001-36
5/16-18X1-1/2 GLIDE




DIMENSION **1** IS FROM THE TOP OF THE OVERHEAD TO THE CENTER OF THE MOUNTING SLOTS ON THE WALL BRACKET. CORRECT ELEVATION FOR THE OVERHEAD MUST BE DETERMINED BY THE INSTALLER / END USER.

MOUNTING THE CABINET TO THE WALL



- 1**. LOWER THE CABINET ON TO THE WALL BRACKET ENSURING THAT ALL TABS MAKE CONTACT WITH THE WALL BRACKET AND ARE FULLY SEATED.
- 2** AFTER THE CABINET IS HUNG AND SECURED TO THE WALL. ADJUST THE BOTTOM GLIDES TO LEVEL THE CABINET VERTICALLY.



- 1 PRIOR TO INSTALLING THE LIGHT INTO THE CABINET, MAKE SURE TO:
 - A INSTALL THE END TABS INTO THE ENDS OF THE LIGHT EXTRUSION.
 - B PRESS SPRING CLIPS ON TO THE BACK OF THE LIGHT EXTRUSION
 - C DETERMINE WHICH SIDE OF THE CABINET THE POWER WIRE WILL BE LOCATED ON AND RUN THE WIRE THROUGH THE BORE HOLE IN THE BOTTOM PANEL AND OUT THE BACK OF THE UNIT.
- 2 PRESS THE LIGHT ASSEMBLY FIRMLY INTO THE BOTTOM PANEL ROUT, MAKING SURE TO COVER THE END OF THE ROUT WITH THE TABS ON THE END CLIPS.