


GUNLOCKE


GENERAL NOTES

1. GUNLOCKE ASSUMES NO RESPONSIBILITY FOR THE METHOD AND FASTENERS USED TO ATTACH BRACKET(S) TO THE WALL. IT IS THE RESPONSIBILITY OF THE INSTALLER / END USER TO DETERMINE THE APPROPRIATE METHOD OF ATTACHMENT BASED ON THE TYPE OF WALL MATERIAL AND OR STUDS AVAILABLE.

WALL MOUNT HARDWARE



WALL MOUNT BRACKET(S)



- 1 DETERMINE THE HEIGHT OF THE TOP OF THE TACK PANEL.
- 2 MEASURE DOWN FROM THE TOP OF THE TACK PANEL TO THE DIMENSION GIVEN AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

- 1 DETERMINE THE BOTTOM OF THE TACK PANEL.
- 2 MEASURE UP FROM THE BOTTOM OF THE TACK PANEL TO THE DIMENSION GIVEN AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.