

# CREDENTIALS HEIGHT ADJUSTABLE EXTENSION WALL ACCESS / FULL MOD ASSEMBLY


AA013-0005-00

## GUNLOCKE

## GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.

## WALL ACCESS PANEL HARDWARE



SA922-0001-35  
PEDESTAL GANGING BRACKET



3500112000  
SCR TP-A 10X5/8 PN PH



12907-4600-35  
9" ANGLE BRACKET




19917-4387-36  
SCR TP-AB 8X1 FT PH




19917-4194-36  
SCR TP-A 8X5/8 PN PH


## FULL MODESTY PANEL HARDWARE



MX907-0089-35  
BRKT MOD PNL



19917-4632-35  
SCR MH 1/4-20X3/4



12907-4600-35  
9" ANGLE BRACKET




19917-4387-36  
SCR TP-AB 8X1 FT PH




19917-4194-36  
SCR TP-A 8X5/8 PN PH

1 ATTACH BRIDGE TO EXTENSION




2 SECURE WORKSURFACE TO EXTENSION



SCALE 0.032

## 1 ATTACH BRIDGE TO EXTENSION



## 2 INSTALL WORKSURFACE BRACKET TO EXTENSION

