


GUNLOCKE

GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.

THERE ARE (4) UNIQUE CHASSIS TYPES. EACH CHASSIS IS ILLUSTRATED.

BRIDGE ASSEMBLY HARDWARE



19907-5164-31
2" ANGLE BRACKET




19917-4194-36
SCR TP-A 8X5/8 PN PH

BRIDGE ATTACHMENT HARDWARE






18907-6791-35
USER SIDE FLAT PLATE





19917-4387-36
SCR 8X1 FT PH

1 ATTACH BRACKETS TO WORKSURFACE



2 ATTACH WORKSURFACE TO MOD PANEL




NOTE: THE BACK SIDE OF THE WORKSURFACE
SHOULD HAVE A CONSISTENT 1/16" OVERHANG



1B. ASSEMBLE STANDARD WALL ACCESS BRIDGE

AA013-0003-00




1 ATTACH BRACKETS TO WORKSURFACE



19917-4387-36
SCR 8X1 FT PH



2 ATTACH BRACKETS TO WALL ACCESS PANEL





19907-5164-31
2" ANGLE BRACKET




19917-4194-36
SCR 8X5/8 PN PH

3 ATTACH WORKSURFACE TO CHASSIS



19917-4194-36
SCR 8X5/8 PN PH






NOTE: WORKSURFACE SHOULD BE INSET FROM
THE BACK EDGE OF THE END PANELS 2-3/4"

2A. ASSEMBLE HEIGHT ADJUSTABLE FULL MODESTY PANEL


AA013-0003-00

1 ATTACH BRACKETS TO WORKSURFACE



NOTE: INSTALL FLAT BRACKETS ON THE OPPOSITE SIDE OF THE EXTENSION

2 ATTACH WORKSURFACE TO MODESTY PANEL





NOTE: WORKSURFACE SHOULD BE INSET FROM THE BACK EDGE OF THE MOD PANEL 1/16"

2B. ASSEMBLE STANDARD WALL ACCESS BRIDGE


AA013-0003-00

1 ATTACH BRACKETS TO WORKSURFACE





NOTE: INSTALL FLAT BRACKETS ON THE OPPOSITE SIDE OF THE EXTENSION

2 ATTACH BRACKETS TO WALL ACCESS PANEL



3 ATTACH WORKSURFACE TO CHASSIS



NOTE: WORKSURFACE SHOULD BE INSET FROM THE BACK EDGE OF THE END PANELS 2-3/4"