

CREDENTIALS ASSEMBLY INSTRUCTION

GUNLOCKE SEGMENTED TACK ZONE

AA013-0020-00

GENERAL NOTES

1. ALWAYS PROTECT THE TACK ZONE DURING INSTALLATION.
2. GUNLOCKE ASSUMES NO RESPONSIBILITY FOR THE METHOD AND FASTENERS USED TO ATTACH BRACKET(S) TO THE WALL. IT IS THE RESPONSIBILITY OF THE INSTALLER / END USER TO DETERMINE THE APPROPRIATE METHOD OF ATTACHMENT BASED ON THE TYPE OF WALL MATERIAL AND OR STUDS AVAILABLE.

TACK ZONE ASSEMBLY HARDWARE




3500009100
SCR TP-A 10X1-3/4 FL PH




0500248400
SCR TP-A 8X5/8 FT PH

WALL MOUNT HARDWARE





WALL MOUNT BRACKET



A INSERT SHELF INTO FRAME





B SECURE SHELF TO FRAME USING SCREWS




3500009100
SCR TP-A 10X1-3/4 FL PH

ASSEMBLE TACK ZONE TO FRAME EXTRUSION



A PLACE TACK ZONE AGAINST FRAME AND
SECURE WITH SCREWS



0500248400
SCR TP-A 8X5/8 FT PH