


GUNLOCKE

## GENERAL NOTES


1. GUNLOCKE ASSUMES NO RESPONSIBILITY FOR THE METHOD AND FASTENERS USED TO ATTACH BRACKET(S) TO THE WALL. IT IS THE RESPONSIBILITY OF THE INSTALLER / END USER TO DETERMINE THE APPROPRIATE METHOD OF ATTACHMENT BASED ON THE TYPE OF WALL MATERIAL AND OR STUDS AVAILABLE.

## WALL MOUNT HARDWARE



WALL MOUNT BRACKET(S)

## SINGLE PIECE TACK ZONE




- 1 DETERMINE THE HEIGHT OF THE TOP OF THE TACK PANEL.
- 2 MEASURE DOWN FROM THE TOP OF THE TACK PANEL TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

- 1 DETERMINE THE BOTTOM OF THE TACK PANEL.
- 2 MEASURE UP FROM THE BOTTOM OF THE TACK PANEL TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

# TWO PIECE TACK ZONE UNDER OVERHEAD

AA013-0017-00




- 1 DETERMINE THE HEIGHT OF THE TOP OF THE TACK PANEL.
- 2 MEASURE DOWN FROM THE TOP OF THE TACK PANEL TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.


- 1 DETERMINE THE BOTTOM OF THE TOP SECTION OF THE TACK PANEL.
- 2 MEASURE UP FROM THE BOTTOM OF THE TOP SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

# TWO PIECE TACK ZONE TOP OF OVERHEAD


AA013-0017-00



- 1 DETERMINE THE HEIGHT OF THE TOP OF THE TACK PANEL.
- 2 MEASURE DOWN FROM THE TOP OF THE TACK PANEL TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.



- 1 DETERMINE THE BOTTOM OF THE TOP SECTION OF THE TACK PANEL.
- 2 MEASURE UP FROM THE BOTTOM OF THE TOP SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.




- 1 DETERMINE THE BOTTOM OF THE TACK PANEL
- 2 MEASURE UP FROM THE BOTTOM OF THE TOP SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

# THREE PIECE TACK ZONE

## TOP OF OVERHEAD

AA013-0017-00



- 1 DETERMINE THE HEIGHT OF THE TOP OF THE TACK PANEL.
- 2 MEASURE DOWN FROM THE TOP OF THE TACK PANEL TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

- 1 DETERMINE THE BOTTOM OF THE TOP SECTION OF THE TACK PANEL.
- 2 MEASURE UP FROM THE BOTTOM OF THE TOP SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

- 1 DETERMINE THE BOTTOM OF THE MID TACK PANEL
- 2 MEASURE UP FROM THE BOTTOM OF THE MID SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.

- 1 DETERMINE THE BOTTOM OF THE TACK PANEL
- 2 MEASURE UP FROM THE BOTTOM OF THE TOP SECTION TO THE DIMENSION GIVEN, AND MARK THE WALL.
- 3 INSTALL THE WALL MOUNT BRACKET TO THE WALL.