


GUNLOCKE


GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.


RUNOFF ASSEMBLY HARDWARE




AA907-1225-24
CLAMEX P-15G



12907-4600-35
9" ANGLE BRACKET



15907-4468-35
1" ANGLE BRACKET




18907-6791-35
6-1/2"X3" FLAT BRACKET



3500112000
SCR TP-A 10X5/8 PN PH



19917-4387-36
SCR TP-AB 8X1 FT PH



1. INSERT THE P-15G CLAMEX FASTENERS INTO EACH GROOVE ON THE WORKSURFACE AND THE END PANEL.
2. PLACE THE PANELS TOGETHER ON THE MITER ANGLE AND USING AN ALLEN WRENCH TURN THE LOCK TAB IN THE CLAMEX FASTENER UNTIL ALL FASTENERS ARE LOCKED TOGETHER.

ASSEMBLE MODESTY PANEL

