



GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNIT(S) AT FINAL LOCATION.


RUNOFF ASSEMBLY HARDWARE



3500009400
SCR TP-AB 10X1 FT PH




19917-4387-36
SCR TP-AB 8X1 FT PH




18907-6791-35
BRKT FLAT PLATE 6-1/2X3

MODESTY ASSEMBLY HARDWARE (OPTIONAL)




SA922-0005-31S
BRKT MODESTY PANEL




19917-4194-36
SCR TP-A 8X5/8 PN PH

ASSEMBLE WORKSURFACE TO FRAME

AA013-0009-00





3500009400
SCR TP-AB 10X1 FT PH



WORKSURFACE HAS POCKETS ON
THE UNDERSIDE THAT THE FRAME
PLATES WILL SIT IN

ATTACH OPTIONAL MODESTY PANEL



SA922-0005-31S

19917-4194-36
SCR TP-A 8X5/8 PN PH

FLAT BRACKET ATTACHMENT LOCATIONS

AA013-0009-00

