


GENERAL NOTES

- 1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
- 2. ALWAYS LEVEL UNITS(S) AT FINAL LOCATION.


ATTACHMENT HARDWARE



19917-4393-36
MH 8-32X3/4"




3500112000
TP-A 10X5/8



AB907-1001-35
BRKT ASHLEY DUO WKSF

- 1 ALIGN POWER UNIT HOLES (4X) WITH THE HOLES ON THE BOTTOM SIDE OF THE BRACKET, USE THE 4 8-32 X 3/4 MACHINE SCREWS AND SCREW THEM IN THROUGH THE THREADED HOLES



- 2 WITH THE POWER UNIT NOW ATTACHED FIRMLY TO THE BRACKET, PLACE THE BRACKET UNDER THE WORKSURFACE IN THE DISIRED LOCATION. USE 4 OF THE 10 X 5/8 SCREWS TO SCREW INTO THE BOTTOM OF THE WORKSURFACE.

