

CAFE WORKBENCH TABLE ASSEMBLY


BB013-0001-00

REV. A - 10-12-16


GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNITS(S) AT FINAL LOCATION.


ATTACHMENT HARDWARE




NUT HX 5/16-18X1/2



WSR 5/16 ID ZN




WSR LOCK 5/16 ID ZN




19962-0001-00
GLIDE & INST. SHEET


- 1 PLACE TABLE UP-SIDE DOWN AND ALIGN ENDS WITH THE HOLES IN THE APRON ATTACHED TO THE TOP




- 2 WITH THE HANGER BOLTS PLACED IN THE APRON HOLES, PLACE THE WASHERS AND NUT ON THE HANGER BOLTS





DETAIL A
SCALE 0.200



- 3 FIRMLY TIGHTEN NUT TO BOLTS & APPLY GLIDES TO LEGS.
WITH ASSISTANCE, CAREFULLY FLIP TABLE OVER



- 4 ONCE RIGHT SIDE UP, SLIDE THE CROSS RAIL DOWNWARD SO THAT ALL MOD-EEZE CLIPS CATCH THE PINS INSTALLED IN THE SIDE RAIL ATTACHED TO THE LEGS



NOTE: AFTER THE CROSS RAIL HAS BEEN LOCKED ONTO THE PINS, THERE SHOULD BE A 1/4" STEP ON BOTH TOP AND BOTTOM OF THE CROSS RAIL

