


In-Use Screen




After a Massage program is selected, you will be taken to the *Body Scanning* screen. Once scan is complete and you are happy with the result, Press OK. If you need to fine tune your scan, you will be prompted to do so in the shoulder adjust screen. Here you can use the arrows to adjust the back mechanism up and down to match your specific shoulder height. Press OK to confirm.




- 1 Top Navigation
- 2 Auto Program
- 3 Adjustments
- 4 Zero Gravity
- 5 Bottom Navigation
- 6 Quick Settings
- 7 Backrest Adjustment
- 8 Lumbar Heat
- 9 Power Button

After adjusting your shoulder height, you will be taken to the *In-use screen* where you can observe all current settings and session information. To personalize your massage to your exact needs, use the top navigation to switch between **Auto**, **Manual**, **Air**, and **Favorite** settings.



Quick Access Panel + Dial & Button Control

The Quick Access Panel + Dial & Button Control allows you to turn the chair on and off and control chair angles.




- **Long Press** the **Power Button** to turn the chair on/off
- **Turn the Dial** right or left to **increase/decrease** the intensity of the 4D back massage mechanism
- **Plugin** your favorite device into the USB-C port
- **Play/Pause** your massage session
- Adjust your backrest up/down
- Turn on/off the foot rollers
- **Press** the **Auto Programs** to change program sessions
- **Press** the **Zero Gravity** button to cycle through stages
- **Press** the **Heat** button to cycle through heat settings

KYOTA | The World's Most Advanced Massage Chairs®
72 Stard Road, Seabrook, NH 03874 | 603-910-5333
www.kyotamassagechairs.com
Version 1.0



Quick Start Guide



Alternatively, **scan the QR code** to watch a remote tutorial video.


Kiyomi™ M698
4D Massage Chair




Auto Mode – Choose from 24 preset auto programs. There are 4 categories with 6 auto programs each.




Manual Mode – Tap screen to control your massage techniques; kneading, tapping/kneading, tapping, clapping, knocking, and shiatsu.



Power Button – Turn your chair on or off using the power button. Simply tap the screen and press either Yes or No.




Home Page – After turning on your chair, this is the first screen you will see on your tablet. Use this screen to navigate all menu options. To select, simply tap the screen with your finger.




Pause/Play – Pause and resume massage sessions simply by tapping the screen.



Air Massage – Choose your desired airbag region/s: Full Body, Arm/Hand, Leg/Foot, Upper Body, or Shoulder. Tap screen to select setting. Selecting Full Body will over ride any selections and ALL airbags become active.



Favorite – Your chair has the ability to save your favorite customized massage programs to memory. Tap to save, "X" to delete, and "Run" to start the program.



Setting – Control a number of settings such as Sleep Mode, Language, Beep Volume, AI Voice, Voice List, Brightness, Bluetooth, Ionizer, and LED Light.