Hipot Testers

HT-S Series





SAFE



RELIABLE







UL LISTED DIELECTRIC WITHSTAND/GROUND CONTINUITY TESTER

The HT-S series Hipot Tester with adjustable voltage output, voltage ramp, test time, leakage current and ground continuity limit setting.



FEATURES

Model HT-2000S, HT-2800S, HT-3000S:

AC Output: 0-2000V Leakage current up to 20mA. DC Output: 0-2800V Leakage Current up to 5 mA.

Model HT-4200S:

AC Output: 0-3000V Leakage current up to 10mA. DC Output: 0-4200V Leakage current up to 5mA.

Logic controlled, one button test, easy to setup, LED's indicate test progress. Upon failure, buzzer sounds and testing is terminated.

Output voltage, leakage current limit, voltage ramp-up time, ground continuity limit and test duration are controlled from the rear panel.

Ground continuity test is defeatable for testing of two wire products.

NEMA 5-15R receptacle provided on front panel for high voltage output. (N/A on HT-4200S)

Operation instructions provided on the rear panel.

UL and c-UL approved

Performs UL and CSA safety agency requirements for production hipot testing.

Can be connected to the GF-30AC-T ground bond tester for complete TUV and European safety testing, with the TESTLINK option. (TESTLINK voids UL Listing).

Supports PLC interface for complete automated testing with the RI option.

Small footprint and lightweight.

Economical, durable and compact.

Calibration certificate included

6" drop tested.

One year calibration cycle.

One year warranty.



HT-S Series



FAST



SAFE



RELIABLE









Specifications

HT-2000S Voltage Test Type: AC

Maximum Output Voltage: 2000 VAC Maximum Leakage Current: 20mA AC

Leakage Current Adjustment: 1-20mA AC, increments of 0.1 mA

HT-2800S Voltage Test Type: DC

Maximum Output Voltage: 2800 VDC Maximum Leakage Current: 5mA AC

Leakage Current Adjustment: 1-5 mA DC, increments of 0.1 mA

HT-3000S Voltage Test Type: AC/DC

Maximum Output Voltage: 2000VAC / 2800VDC
Maximum Leakage Current: 20mA AC / 5mA DC

Leakage Current Adjustment: 1-20mA AC / 1-5mA DC, increments of 0.1 mA

HT-4200S Voltage Test Type: AC/DC

Maximum Output Voltage: 3000VAC / 4200VDC Maximum Leakage Current: 10mA AC / 5mA DC

Leakage Current Adjustment: 1-10mA AC / 1-5 mA DC, increments of 0.1 mA

All Models Input Voltage: 120 VAC

Frequency: 60 Hz

Fuse: 120/230 VAC 2 A Slow Blow

Breakdown Detect: Independent High Frequency Circuit (50 KHz – 500 KHz)

Transformer Power: < 500 VA

Leakage Current Detect: Independent Low Frequency Circuit

Ramp Time Range: 1 - 5 Seconds
Test Time Range: 1 - 60 seconds
Discharge Time: <7ms for AC

<1.3s for Max DC at Open Circuit

Display: 4 Digits LED Display

Voltage Meter Accuracy: \pm 2 % Leakage Accuracy: \pm 0.1 mA

Ground Continuity: $0.08\Omega - 1.50\Omega$ increments of 0.01Ω

Defeatable

Min. Current: 100mA \pm 0.02 Ω Accuracy

Duty Cycle: 100 % Pass/Fail Repeatability: ± 3%

Operation Temperature: 15 - 40 °C

Relative Humidity Range: 0 - 90 % Non-Condensing

650 Gateway Center Way, Suite D. San Diego, CA 92102 USA Toll Free: (800) 748-6224 Phone: (619) 878-9696



HT-S Series



FAST



SAFE



RELIABLE







General

HT-2000S, HT-2800S, HT-3000S

Output Connector: NEMA 5-15R Receptacle and 4mm H.V. Socket output

Dimensions: 9-1/4" Wide x 4-3/4" High x 10" Deep

Weight: ~11 lbs

Product Package: HT-S Hipot Tester

HT-S Product Manual 18 AWG Line Power Cord

Ground Return Lead, 18AWG, 4ft long (1 x PN:00-GL) Ground Continuity Connector Tip (1 x PN: 00-GPIN) NIST Traceable Calibration Certificate to MIL-STD45662-A

Calibration Data Copy

HT-4200S

Output Connector: 4mm H.V. Socket output

Dimensions: 9-1/4" Wide x 4-3/4" High x 10" Deep

Weight: ~11 lbs

Product Package: HT-S Hipot Tester

HT-S Product Manual 18 AWG Line Power Cord

Ground Return Lead, 18AWG, 4ft long (2 x PN:00-GL-S) High Voltage Test Lead, 5kV, Red 4ft long (1 x PN:00-HVTL-R-4) NIST Traceable Calibration Certificate to MIL-STD45662-A

Calibration Data Copy



Options

00-HVTL-R-6 High Voltage Test Lead, 5Kv, Red 6ft long

00-TL TestLink option. Allows connection with GF-30AC-T for Ground Bond Test

00-TLC TestLink Cableset. (For 00-TL)

00-RI Relay Interface/PLC Interface. Test signals through relay contacts/coils

00-AR Auto Reset on Pass option. Resets after passing test

00-HTT-1S Function Checker: Allows verification of functionality/calibration of your tester.
00-HTT-1R Function Checker: Allows verification of functionality/calibration of your tester.

Different models available (LomA, MedmA, HimA, ExmA and Custom)

Z

Safety

Output Voltage Indicator: Provided by front panel meter, directly connected to high voltage output.

Failure Indicator: Visual, Provided by red LED's.

Test automatically terminated on failure.

Leakage Test: Factory setting set for pass/fail point (also user adjustable)

5mA AC and 2mA DC

Operation Instructions Provided on rear panel

650 Gateway Center Way, Suite D. San Diego, CA 92102 USA Toll Free: (800) 748-6224 Phone: (619) 878-9696

