


Digital Storage Oscilloscope 60 MHz, 400 MSa/s

Model 2534



FFT spectrum analysis screen

**FULL FEATURED OSCILLOSCOPE
THAT WON'T BREAK YOUR BUDGET**

The model 2534 dual channel Digital Storage Oscilloscope delivers an unmatched combination of performance and value. Analog style controls combined with an Auto measurement function make this oscilloscope easy to use. Advanced features such as FFT function, digital filtering, waveform recorder, delayed sweep/zoom, mask testing and automatic measurements provide you with powerful tools to debug your circuits.


The 2534 comes with PC Software that lets you easily capture, save and analyze waveforms and measurement results. Unlike other DSOs in this price category, the 2534 includes two 150 MHz high performance passive probes that will not limit the bandwidth of your measurement system.

The 2534 is an ideal instrument for education and training and also well suited for design and debug, service and repair.

Features

- 60 MHz bandwidth, 400 MSa/s real time sample rate
- 4000 point record length for each channel
- Color LCD display
- USB front panel host port for USB flash drives standard
- USB device interface standard
- Advanced features include digital filter with adjustable limits, mask testing and waveform recorder/replay mode
- 24 automatic measurements
- FFT standard plus 3 additional math functions
- Extensive Trigger capabilities including pulse width and line-selectable video trigger
- Multiple language interface
- PC Software that lets you fully control the oscilloscope via a virtual front panel and transfer waveform data to a Windows PC for storage and further analysis

▲ Front panel features



1) USB host port

Connect your USB flash drive to conveniently store and recall waveform data (binary or csv), setups and screen shots (bmp format). You can also update the oscilloscope's firmware from this port.

2) Easy setup and use

The Auto button identifies the input signal and automatically sets up the vertical, horizontal and trigger controls to produce a useable display.

You can automatically adjust the timebase to view the waveform area of interest by selecting option single cycle or multiple cycle.

3) Print button

Simply press the Print button to quickly save a screen shots in bitmap format to a USB flash drive

4) Menu On/Off button

Configure the menu parameters then hide the menu with the push of a button to view your signal on the full screen (12 divisions).

5) Advanced triggering

Isolate the signal with advanced triggering including pulse width and selectable video trigger. Use the alternate trigger function, typically only found in analog oscilloscopes, for a stable display of signals unrelated in time.

6) Waveform analysis with math and FFT

Analyze your signals with add, subtract and multiply functions. View the signal's frequency spectrum and perform harmonic distortion analysis.

7) Time and date stamp

Save files to external memory complete with time and date stamp to help you stay organized.

8) Auto calibration

Automatically calibrate the instrument's vertical and horizontal system for optimum measurement accuracy


Convenient Storage Compartment



Store accessories in the oscilloscope's storage compartment and keep your work bench clutter free


▲ The tools you need

Delayed Sweep/Zoom




Use the oscilloscope's delayed sweep feature to zoom in on a particular area of the signal in real time while still viewing the entire captured waveform.

Powerful measurement functions




Display and measure the input signal's frequency spectrum. Select one of the 5 FFT windows: Rectangular, Hanning, Hamming, Blackman and Flattop. Use cursors to measure the spectral component's magnitude and frequency.

User friendly interface for file handling




Navigate your USB flash drive directory and files with ease. Store and retrieve waveform data, screen shots and setups complete with time and date stamp and used defined names.

Mask testing




Create a user defined mask (pass/fail limits) and automatically compare it against the input signal from CH1 or CH2. This feature is ideal for manufacturing test applications that require instant go/no go test results.

Auto measurement




Increase your efficiency by viewing twenty common measurements simultaneously.

Digital filtering




Noisy signal



Noise free signal after application of digital lowpass filter

Filter out unwanted signal components, such as various types of noise, with the built in digital filter. Select from lowpass, highpass, bandpass or notch filter. The limits are adjustable over a wide range. The available range varies with each timebase settings. (e.g. the lowpass filter corner frequency can be set as low as 40 Hz when selecting a timebase of 5 ms/div).

Waveform Recorder



Monitor and analyze long term signal behavior by recording data continuously over long periods of time then playing it back for post acquisition analysis. Data is recorded in a sequence of up to 1000 frames of 4 k data points each and the time interval between each frame is adjustable from 1 ms – 100 s. The data can be saved to a single file to internal memory or USB flash drive

Specifications		model
		2534
Performance Characteristics		
Bandwidth	60 MHz	
Real time sample rate	400 MSa/s (2 channels interleaved)	
Channels	2	
Display	5.7 inch (145 mm) diagonal Color LCD	
Rise Time	<5.83 ns	
Record Length	4000 points	
Vertical Resolution	8 bits	
Vertical Sensitivity	2 mV - 5 V/div	
DC gain accuracy	±3.0 %	
Maximum Input Voltage	400 Vpk, CAT II (between signal and reference BNC connector)	
Position Range	± 8 divisions from center of screen	
Bandwidth Limit	20 MHz	
Time Base range	2.5 ns/div – 50 s/div	
Timebase accuracy	100 ppm	
Input Coupling	AC, DC, GND	
Input Impedance	1 MΩ in parallel with 19 pf	
Vertical and Horizontal Zoom	Vertically or horizontally expand or compress a live or stopped waveform	
I/O interface	USB host port on front panel supports USB flash drives. USB device port for connection to PC (Requires included Comsoft Software for use)	
Acquisition Modes		
Sample	Display sample data only	
Peak Detect		
Average	Waveform averaged, selectable from 2, 4, 16, 32, 64, 128, 256	
Roll Mode	For time base settings 500 ms/div-50 s/div	
Trigger System		
Trigger Types	Edge, Pulse Width, Video*	
Trigger Modes	Auto, Normal, Single	
Trigger Coupling	AC, DC, LF reject, HF reject	
Trigger Source	CH1, CH2, AC line, Ext, Ext/5	
*Support formats PAL/SECAM, NTSC. Triggers on odd or even field, all lines or line number		
Cursors		
Types	Amplitude, Time	
Measurements	ΔV, ΔT, 1/ΔT	

Automatic Waveform Measurement	
Time	Rise time, Fall Time, Cycle Frequency, Period, Positive Pulse Width, Negative Pulse width, Delay, Phase, X at Min, X at Max
Voltage	MAX, MIN, Peak-Peak, Average, Vrms, High, Low, Amplitude, Cycle RMS, Cycle Average, Overshoot, Preshoot
Frequency	Hardware counter provides frequency readout of trigger source with 5 digit resolution
Waveform Math	
Math function	FFT, add, subtract, multiply, divide
FFT	Windows: Hanning, Hamming, Blackman, Rectangular, Flattop, 2048 sample points
Autoset	
Single button automatic setup of both channels for vertical, horizontal and trigger systems	
Display	
Display Mode	1/4 VGA (5.7") 256 color LCD (320x240) with adjustable contrast and inverse video
Display Types	Point, Vector
Persistence	Off, infinite
Waveform Interpolation	Sin(x)/x, Linear
Format	YT and XY
Power Requirements	
100-240 VAC, 50 VAmx, 47 Hz to 440 Hz	
Environmental	
Temperature	Operating: 0° C to +40° C Nonoperating: -20° C to +55° C
Humidity	Operating: 95 % RH, 40° C Nonoperating: 90 % RH, 55° C
Altitude	Operating to 3000 m
Pollution Degree	Pollution degree 2 for indoor use only.
Electromagnetic compatibility and Safety	
EMC	This oscilloscope is in compliance with council EMC directive 2004/108/EC
Safety	EN61010-1:2001
General	
Dimensions	310 mm (W) x 147 mm (H) x 269 mm (D)
Width x Height x Depth	12.2 in x 5.8 in x 10.6 in
Weight	3.6 kg (8 lbs)
Two Year Warranty	
Accessories	
Supplied: User Manual, Two 150 MHz 10:1 passive probes (model PR 37A), Power cord , USB interface cable, Comsoft Software Installation disk	
Optional: PR 32A Demodulator Probe, PR 55 High Voltage Probe	