# **Manual Supplement**

Manual Title:287/289 Getting StartedPart Number:2748860Print Date:June 2007Revision/Date:1, 3/09

Supplement Issue:3Issue Date:6/10Page Count:2

This supplement contains information necessary to ensure the accuracy of the above manual.



287/289 Getting Started

Manual Supplement

### Change #1, 54932

In the Specification section on page 6, under **Electromagnetic Compatibility Standards (EMC)**, replace the **Certifications** with following:

Certifications.....UL, CE, CSA, 😋 (N10140), 🕲

#### Change #2, 55189, 55213, 55269

On page 3, Table 1, replace the TUV symbol with the following:

From: 🞯 🗲

To: 🕑

In the Specification section on page 11, under **Resistance Specifications**, change the **Accuracy** for 500 k $\Omega$ :

From: 0.05 % + 2 To: 0.05 % + 15

In the Specification section on page 13, under *Frequency Counter Specifications,* add a footnote 3 to the Duty Cycle row.

[3] For 10  $\mu$ s < pulse width <25  $\mu$ s add 1%. For 2  $\mu$ s < pulse width  $\leq$ 10  $\mu$ s add 3.5 %.

Under Pulse Width, change the Accuracy for 0.1000 ms:

From: 0.002 ms + 3 counts To: 0.002 ms + 30 counts Manual Supplement

In the Specification section on page 15, under Typical Short Circuit Current, change 5 MΩ:

From: 0.3 μA To: 1 μA

## Change #3, 55354

In the Specification section on page 5, under the *General Specifcations*, replace the **Safety Standards**, with the following:

#### Safety Standards

US ANSI	. ANSI/ISA 61010-1 2004 (82.02.01):2004
CSA	. CAN/CSA-C22.2 No 61010-1-04
UL	. UL 61010-1:2004
CE European	. IEC/EN 61010-1 2 <sup>nd</sup> Edition
Pollution Degree	. 2

