

# Supplement

Title: 902 Users Supplement Issue: 1  
Part Number: 2547887 Issue Date: 3/07  
Print Date: May 2006 Page Count: 2  
Revision/Date: 1, 3/07

---

---

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.

**T**equipment  
|.NET



205 Westwood Ave  
Long Branch, NJ 07740  
1-877-742-TEST (8378)  
Fax: (732) 222-7088  
salesteam@Tequipment.NET

## Change #1

On page 23, under **Electrical Specifications**, replace the Temperature row with the following:

Temperature	-40 to 400 °C	0.1 °C	-40 to -10 °C $\pm 5.0\%$ + 1.5 °C typical  -10 to 400 °C $\pm 1.0\%$ + 0.8 °C typical
-------------	---------------	--------	--

## Change #2

On page 3, under **Read First: Safety Information**, replace the 4<sup>th</sup> bullet with the following:

- Never use the Meter on a circuit with voltages higher than 600 V or a frequency higher than 60 Hz fundamental. The Meter may be damaged.**

On page 4, replace the third bullet with the following:

- To avoid false readings that can lead to electrical shock and injury, replace the batteries as soon as the low battery indicator (🔋) appears.**

On page 11, replace the first bullet with the following:

- If the resistance is  $< 30 \Omega$ , the continuity beeper will sound.

On page 20, under **Maintenance**, add the following note:

*Note*

*When the Meter displays CAL, the unit will lock and no measurements can be made. The Meter must be sent to a Fluke Service Center for repair.*

On page 25, change **Design Standards and Compliance**:

From: IEC 61010, IEC 61010-2-032, CE

To: EN/IEC 61010-1, EN/IEC 61010-2-032  
and relevant U.S. and Canadian  
Standards.

Replace the **Over-voltage Category** entry with:

**Measurement Category** 600 V, CAT III