
# **EXTECH**°

#### **USFR MANUAL**

## Model ET15 - Receptacle Tester

- \*Tests for faulty wiring in 3-wire receptacles
- \*Tests Reversed/ Open Connections
- \*Detects 5 separate faults



### **Operating Instructions**

- 1. Always test on a known good circuit before use
- 2. Refer all indicated problems to a qualified electrician
- 3 Interpret the LEDs as follows:
- 4. The tester will not indicate the quality of the ground connection, 2 hot wires in a circuit, a combination of defects, or reversal of ground and neutral conductors.

OPEN GROUND		
OPEN NEUTRAL		
OPEN HOT		
HOT & GND REV		
HOT & NEU REV		
CORRECT WIRING	П	

#### **Two-year Warranty**

**Teledyne FLIR LLC warrants this Extech brand instrument** to be free of defects in parts and workmanship for **two years** from date of shipment (a six-month limited warranty applies to sensors and cables). To view the full warranty text please visit: <a href="http://www.extech.com/support/warranties">http://www.extech.com/support/warranties</a>.

#### **Calibration and Repair Services**

**Teledyne FLIR LLC offers calibration and repair services** for the Extech brand products we sell. We offer NIST traceable calibration for most of our products. Contact us for information on calibration and repair availability, refer to the contact information below. Annual calibrations should be performed to verify meter performance and accuracy. Product specifications are subject to change without notice. Please visit our website for the most up-to-date product information: <a href="https://www.extech.com">www.extech.com</a>.

## **Contact Customer Support**

Customer Support Telephone List: https://support.flir.com/contact

Calibration, Repair, and Returns: repair@extech.com

Technical Support: <a href="https://support.flir.com">https://support.flir.com</a>

Copyright © 2021 Teledyne FLIR LLC