

Manual Supplement

| | | | |
|----------------|--------------------------|-------------------|----------|
| Manual Title: | 1586A Safety Information | Supplement Issue: | 2 |
| Part Number: | 4107834 | Issue Date: | 1/14 |
| Print Date: | June 2013 | Page Count: | 1 |
| Revision/Date: | | | |

This supplement contains information necessary to ensure the accuracy of the above manual.

FLUKE®

Calibration

Change #1, 66773

On page 1, under **Safety Specifications**, replace **Input Protection** and add:

Safety

Mains Input IEC 61010-1, Overvoltage Category II, Pollution Degree 2
 Measurement Input 50 Vdc max, all functions and ranges.

Electromagnetic Environment IEC 61326-1: Basic (Controlled EM for full specification)

Radio Frequency Emissions IEC CISPR 11: Group 1, Class A. (Group 1 has intentionally generated and/or uses conductively coupled radio-frequency energy which is necessary for the internal functioning of the equipment itself. Class A equipment is suitable for use in non-domestic locations and/or directly connected to a low-voltage power supply network.)


Change #2, 362

On page 1, under **Safety Specifications** add:

Electromagnetic Compatibility..... Applies to use in Korea only. Class A Equipment (Industrial Broadcasting & Communication Equipment) ^[1]

[1] This product meets requirements for industrial (Class A) electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and is not to be used in homes.

On page 3, add the following to the **Symbols** table:

| | |
|---|--|
|  | Conforms to relevant South Korean EMC Standards. |
|---|--|