
































56402 Genius Stand



Assembly Instructions

Part	Drawing	Description	Qty	Part	Drawing	Description	Qty																																
P1		Left Leg	1 EA	<h3 style="text-align: center;">Hardware List</h3> <table border="0"> <tr> <td>A</td> <td></td> <td>Screw M6X8mm</td> <td>4 EA</td> </tr> <tr> <td>A1</td> <td></td> <td>Screw M8X40mm</td> <td>4 EA</td> </tr> <tr> <td>B</td> <td></td> <td>Knob</td> <td>2 EA</td> </tr> <tr> <td>C</td> <td></td> <td>Threaded Square Washer</td> <td>2 EA</td> </tr> <tr> <td>D</td> <td></td> <td>Caster Wrench</td> <td>1 EA</td> </tr> <tr> <td>E</td> <td></td> <td>5" Locking Caster</td> <td>2 EA</td> </tr> <tr> <td>F</td> <td></td> <td>5" Caster</td> <td>2 EA</td> </tr> <tr> <td>G</td> <td></td> <td>Allen Wrench</td> <td>1 EA</td> </tr> </table>				A		Screw M6X8mm	4 EA	A1		Screw M8X40mm	4 EA	B		Knob	2 EA	C		Threaded Square Washer	2 EA	D		Caster Wrench	1 EA	E		5" Locking Caster	2 EA	F		5" Caster	2 EA	G		Allen Wrench	1 EA
A		Screw M6X8mm	4 EA																																				
A1		Screw M8X40mm	4 EA																																				
B		Knob	2 EA																																				
C		Threaded Square Washer	2 EA																																				
D		Caster Wrench	1 EA																																				
E		5" Locking Caster	2 EA																																				
F		5" Caster	2 EA																																				
G		Allen Wrench	1 EA																																				
P2		Right Leg	1 EA																																				
P3		Lower Cross Brace	1 EA																																				
P4		Stability Panel	1 EA																																				
P5		Short Bracket	2 EA																																				
P6		Long Bracket	2 EA																																				

Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.

Assembly Diagram

READ THROUGH INSTRUCTIONS FROM BEGINNING TO END BEFORE STARTING TO ASSEMBLE UNIT.

- 1.) Identify and Separate all the Parts and Hardware.
- 2.) Attach Left and Right Legs (P1 & P2) to the Lower Cross Brace (P3) using 4 screws (A1) as shown in illustration # 1. Finger tighten only at this point.




Illustration # 1

- 3.) Determine the height you want the Stability Panel (P4) so it will work with your size board. Attach the Stability Panel (P4) to the Left and Right Legs (P1 & P2) using 4 screws (A) as shown in illustration # 2. Tighten all Screws with Allen Wrench (G).






Illustration # 2


- 4.) Attach 2 Locking Casters (E) and 2 Casters (F) to the bottom of the Left Leg (P1) & Right Leg (P2) as shown in illustration #3. Tighten all casters with Caster Wrench (D).




- 5.) Place a Threaded Square Washer (C) on top of a Long Bracket (P6) and insert both into one of the bracket holders at the bottom of the Stability Panel (P4). Secure the two using one Knob (B) as shown in illustration #4. Repeat this Step for the other side.



- 6.) Your Genius Stand is shipped with two Long Brackets (P6) installed at the top. You may need to change these brackets and use two Short Brackets (P5) if your board is thinner. See illustration #5.



56402 Genius Stand



56402_04-25-14