TECHNICAL SPECIFICATIONS

HDX-100 Specifications		
Function/Model	HDX-100	
VIDEO INPUT		
Bandwidth	1.65Gps	
Connector	HDMI Connector x1	
HDMI OUTPUT DISPLAY		
HDMI Connector	x 1	
RJ45 Jack	x 1	
Max. Resolution	1920 x 1200 or 480p/720i/720p/1080i/1080p	
Bandwidth	1.65Gps	
Storage Temperature	-20°C~60°C	
Power adaptor	PS5VDC2A	
Housing	Metal	
Dimension(mm)	2.75"W x 3.875"L x 1"H	

© Copyright 2017 Smart-AVI, All Rights Reserved

Notice

The information contained in this document is subject to change without notice. Smart-AVI makes no warranty of any kind with regard to this material, including but not limited to, implied warranties of merchantability and fitness for any particular purpose.

Smart-AVI will not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

No part of this document may be photocopied, reproduced or translated into another language with out prior written consent from Smart-AVI.



User Manual

HDX-100

HDMI Extender over CAT6 STP



HDMI Extender

Smart-AVI

11651 Vanowen St. North Hollywood, California 91605 Ph: (818) 503-6200 : Fax: (818) 503-6208

INTRODUCTION

The HDMI signal transmission unit is placed near the HDMI source. Connect the HDMI source to the transmission unit, which will extend the signal up to 150 feet over a single CAT6 STP cable.

FEATURES

- Compact Transmitter/Receiver Units
- Local HDMI Output
- Perfect Image Quality at all Resolutions (1920 x 1200, 480p, 720i, 720p, 1080i, 1080p)
- Video Resolutions up to 1920 x 1200 at 60H (1280 x 1024 at 75Hz) on all Distances to the Maximum Limit
- Bandwidth to 1.65Gps
- Unit Operates Regardless of Local Monitor Connectivity
- Distances up to 150 Feet using CAT6 STP Cabling
- Compatible with all Operating Systems
- Plug-and-Play No Software Required


WHAT'S IN THE BOX?

Please check the contents of the package before beginning installation.

Qty	Description	Part Number
1	HDX Transmitter, HDMI over CAT6 STP Cable	HDX-TX100
1	HDX Receiver, HDMI over CAT6 STP Cable	HDX-RX100
1	PowerSupply 5VDC 2A	PS5VDC2A

HDX-100

Connection Diagram





INSTALLATION AND OPERATION

Connecting the Splitter/Extender:

- Connect the HDX-100 to the Component/TV/Monitor with HDMI cable (included with the unit).
- 2. Connect HDX-TX100 to HDX-RX100 via CAT6 STP.
- 3. Connect HDX-RX100 to display.
- 4. Connect the power.



