ClareHAL 104 Electrical Safety Tester



Technical Data Sheet





ClareHAL 104 helps production line test process by:

- Improving productivity
- □ Increasing efficiency
- Stores results automatically
- Custom Pass/Fail levels
- Safety guard operation
- IEC/EN International Standards compliance
- Fast testing



ClareHAL 104. A combined AC Ground Bond, AC/DC Hipot, DC Insulation Resistance Tester with Power, Load and Leakage capabilities.

ClareHAL 104 is designed to offer advanced automation techniques which can make dramatic improvements in productivity and efficiency of the production line manufacturing test process.

COMPLIANCE – Standards and Directives

Validation testing is essential for manufacturers to ensure compliance with legislation for their products including CE marking. Electrical safety testing specialists Seaward have produced the HAL series that performs all of the applicable tests needed for demonstrating compliance with EU Directives, International, European and UK standards in one convenient package.

The ClareHAL 104 will help you meet your legal obligations.

All basic tests, as specified in widely used product and safety standards, are included:

- Earth Bond/ Ground Bond testing
- DC Insulation Testing
- AC/DC Flash/ Hipot/Dielectric withstand testing
- Functional/ Run testing
- Touch/Leakage Current testing

Test Methods using the ClareHAL 104

The ClareHAL 104 Tester can be used in three modes – automatic, manual and direct pc control via the external communications port.

Automatic Mode

In automatic mode complete test sequences are stored in the memory and new sequences can programmed using testcodes. Up to 5 tests can be linked into 1 sequence, all tests are timed and all results are stored in memory.

Automatic mode provides a structured, repeatable route to testing which ensures all data is collected for traceability and auditing.

This mode is intended for standard production line use.

Manual Mode

Manual mode provides a quick, simple route to tests and is intended for use in the laboratory, repair or re-test environments where ease of use and quick repeatable tests are are paramount.

Manual mode can be initiated by a one button press and allows individual tests to be performed more freely.

The type of test and its parameters are entered into the tester. The output can be maintained continuously, varied by means of the rotary encoder or timed as in automatic mode.

A facility to store results is available although this is not necessary to perform tests.

Key features

- Function/Power/Load/Leakage/ Touch current test
- Flash/Hipot/Dielectric Strength test
- Ground/Earth Bond test at 40A
- Fast testing production efficiency savings
- Compact unit
- Tests in accordance with IEC/EN/UL International Standards
- Isolated test outputs on Flash/Hipot/Dielectric
 Strength/Insulation test to aid with EN 50191 and for safety
- Arc Detect
- Regulated outputs on Flash/Hipot/Dielectric Strength, Insulation and Ground/Earth Bond tests – independent of supply fluctuations
- PLC control. Simple command protocol for external control via communications port



Select the ClareHAL unit which suits your requirements

Features	100	101	102	103	104
Earth/Ground Bond					
AC Flash/Hipot					
DC Flash/Hipot					
DC Insulation Resistance					
ARC Detection					
Leakage					
Load Power					
Power Factor					
Results Memory					
Automation Option					
Barcode Scanner/Printer Option					
Internal scanner					

Direct PC Control

Simple command protocols are incorporated to enable the product to be controlled directly by a PC or other device connected to the external control port. This level of control is particularly advantageous where the application requires a number of events to occur before test measurements are valid or if a number of measurements need to be taken and synchronized with each event. A typical example requiring this level of control would be the testing of equipment that has several modes of operation, each having the potential to present errors that would not be apparent until the product has reached the applicable state such as a washing machine.

PLC Control

A PLC can be used to control the ClareHAL unit via the external control ports. PLC control can be initiated with a barcode reader or simulation of the barcode protocol.

TESTING - General

The unit can perform either continuous or timed tests, except the Earth/ Ground bond test which is timed. If during the Hipot test, the arc detect level is exceeded the test will be halted and the output removed.

A beeper is present to let the user know that a test fail condition has occurred. The Reset button will clear the condition back to a default screen.

If the programmed limit is exceeded at any time during a test, the unit will display the appropriate test fail message. If the test fails the unit will light the red fail indicator, and sound the audible alarm.

If hazardous voltages (50V AC or DC) are present on the outputs of the unit, this will be indicated by a red warning indicator and a "lightning strike" icon will blink on the display. Also the HT present LED indicator will illuminate adjacent to the test output sockets.

Auto discharge - at the end of Insulation and Hipot testing test all capacitances and inductances will be automatically discharged.

The tester would normally be used with a test fixture or guard system and no tests can be performed without positive confirmation that the guard is in place. If the guard is opened or the Reset button is pressed at any time, the test will be halted and an appropriate test fail message will be displayed.

Key features

- Visual and audible pass/fail indication
- Operation from 115 and 230 V (nom.), 50 or 60 Hz mains supply.
- Barcode scanner support
- Storage of test results
- Large graphical display
- Selectable 50 or 60 Hz output frequency for AC tests.
- External scanner switching matrix for high voltage and high current switching (optional)
- Safety enclosure (optional)



Earth/ Ground Bond test

The unit generates a constant current output independent of input voltage, which is ramped linearly to the set value. The voltage across and current through the ground connections of the equipment under test are continuously measured and the impedance calculated and displayed in real-time.

The parameters that can be set with this test are:

- Test Current the desired test current up to 40A (time limited)
- Ramp up the time required for the current to be ramped from zero to the desired test current
- Ramp hold the time required for the constant test current to be applied
- Ramp down the time required for the test current to be ramped down to zero amps
- Resistance Limit in (mΩ)

Hipot/Dielectric strength test

The voltage generated by this test is isolated at the test outputs for assisting with complying with EN 50191. This test can be timed or continuous.

The unit will generate a regulated Hipot test voltage (independent of the supply voltage), which is ramped linearly to the desired value. The unit will then sample the total leakage current and display it in real-time. The unit will compare the instantaneous measured total leakage against the upper programmed leakage limit to indicate pass or fail. There is a programmable upper and lower limit which ensures that there is a positive indication that the Hipot probe has been connected.

The parameters that can be set with this test are:

- Test Voltage the desired test voltage
- Ramp up the time required for the voltage to be ramped from zero to the desired test voltage
- Ramp hold the time required for the constant voltage to be applied

- Ramp down the time required for the test voltage to be ramped down to zero volts
- Total Leakage limit upper (mA)
- Total Leakage limit lower (mA)
- Arc detection level

All times will be configurable between 0.1 and 300s. The displayed Total Leakage value will be displayed from 0.01 to 10mA (DC) and 0.01 to 20mA (AC). The arc detection level can be programmed between 0 and 10, where 0 disables the function altogether, and 10 provides the least sensitive setting.

Insulation Test

An insulation resistance measurement at a DC test voltage of 250V, 500V or 1000V is available. This test can be continuous or timed.

The selected voltage is ramped linearly to the desired value, where it is then held.

The insulation resistance is displayed in real time.

If this value is less than the minimum pass value programmed, then the appropriate fail message is displayed along with the red fail indicator

The parameters that can be set with this test are:

- Test Voltage which can be pre-selected for 250V, 500V or 1000V
- Ramp up the time required for the voltage to be ramped from zero to the desired test voltage
- Ramp hold the time required for the constant voltage to be applied
- Ramp down the time required for the test voltage to be ramped down to zero volts
- Insulation Resistance value, lower limit (MΩ)

Functional/Run/Leakage test

An operational test will be conducted at the value of the input supply voltage. The measured power of the unit under test will be displayed in real time.

An auxiliary input is provided so that any voltage up to 300V AC can be used in conjunction with the powered test. A simple switch is used to choose between the supply input and Aux input for powered tests.

The parameters that can be set with this test are:

- Load Power Min/Max Value (kVA)
- Power Factor Min/Max Value (Ratio)
- Leakage Current Min/Max Value (mA)
- Touch Current Min/Max Value (mA)

The touch current test will be conducted at the value of the supply and applied via the probe. The measured touch current will be displayed in real time and will use the body model in BS EN 1010 fig A1 Annex A and BS 60990 fig 4.



SPECIFICATIONS: ClareHAL 104, 103, 102, 101, 100

Power Requirement

AC Voltage Frequency Selectable 115 or 230V AC RMS 50/60 Hz

Mechanical Specification

Size (HxWxL) Weight 300mm-200mm-370mm 15kg Approx

Ground Bond Test - 104, 103, 100

Test Voltage	Nominal 6V AC
Frequency	50 or 60 Hz (Independent
	of supply)
Display Range and Accuracy	0-1500m Ω ±2% ±5 Counts
Display Resolution	1 m Ω
Compliance Test Ranges:	
Current/Load Resistance/Time	5 A-1000m Ω - Continuous
	10 A-500m Ω - Continuous
	25 A-200 m Ω - Continuous
	30 A-150 m Ω - 60 secs
	40A-100 m Ω - 60 secs
Settable Output Current Range	0.1A-40.0A
Selectable Range of Pass/Fail Levels	0-1500m Ω

Insulation Resistance Test - 104, 103, 102, 101

DC Output Voltage	0.10kV-6.00kV	
	(10V/Step when manually adjusted)	
	(50V/Step in test sequence program)	
Display Range	0.01ΜΩ-500ΜΩ	
Display Range / Accuracy	$0.03M\Omega$ -350M Ω ± 5% ± 5 Counts	
	350MΩ-500MΩ Indication Only	
Display Resolution	0.01MΩ	
Pass/Fail Level	0.00ΜΩ-500.0ΜΩ	

AC Flash / Hipot Test - 104, 103, 102, 101

Programmable Voltage Range	0.10kV-5.00kV
	(10V/Step when manually adjusted)
	(50V/Step in test sequence program)
Frequency Independent of Supply	50 or 60 Hz
Voltage Display Range and Accuracy	0.10kV-5.00kV ±1% ± 5 Counts
Voltage Display Resolution	0.01kV
Current Display Range and Accuracy	0.01mA-20.00mA ±1% ± 5 Counts
Current Display Resolution	0.01mA
Selectable Range of Pass/Fail Levels	0.01mA-20.00mA
Maximum Current Output	20.00mA @5kV
Optional Arc Detection	9 Levels

Accessories

- Hipot Probe & lead Part number: 03918/2
- Hipot Clip (Std. Black) & lead Part number: H-5003
- Hipot Clip (Red) & lead Part number: H-5003/R
- Ground Bond Clip Lead Part number: 01521/1
- Hand Held Guard Switch Part number: DCS317
- Calibration Checkbox Part number: V242
- CCD Barcode Scanner Part number: 194A922
- Status Beacon (mains cord 230/110V)
 Part number: H – 5017
- Enclosures ENC 6: W300mm x H240mm x D280mm

Part Number: 73B239

ENC 7:

W600mm x H475mm x D280mm Part Number: 73B240

- EN50191 Kit
- Switching Matrix Part number: 485A910
- PowerSmart

1 phase Part number: 483A910



DC Flash / Hipot Test - 104, 103, 102, 101

Programmable Voltage Range

Voltage Display Range and Accuracy Voltage Display Resolution Current Display Range and Accuracy 0.01mA-10.00mA ±1% ± 5 Counts Current Display Resolution Selectable Range of Pass/Fail Levels 0.01mA-10.00mA Maximum Current Output **Optional Arc Detection**

0.10kV-6.00kV (10V/Step when manually adjusted) (50V/Step in test sequence program) 0.10 kV-6.00kV ±1% ± 5 Counts 0.01kV 0.01mA 10.00mA 9 Levels

Power and Leakage Test - 104 only

Power Output Rating

Test Voltage

Maximum Power Output

110V - 230V AC 20A nominal (Vin-Vout) Up to 5.0kVA (dependant on mains supply rating)

Output Power Measurement

Single Phase Power Measurement Display Range and Accuracy Selectable Range of Pass/Fail Levels

0.02kVA-5.00kVA ±2% ±0.02kVA 0.001kVA-5.000kVA

Single Phase Power Factor Measurement

Display Range and Accuracy Ratio 0.000 -1.000 ± 0.030 Selectable Range of Pass/Fail Levels 0.000-1.000

Leakage Current Measurement

Display Range and Accuracy **Display Resolution** Selectable Range of Pass/Fail Levels 0.01mA-20mA

0.10mA-20.00 mA ± 1% ±5 Counts 0.01mA

Touch Current Measurement

Display Range and Accuracy **Display Resolution** Selectable Range of Pass/Fail Levels Measuring Device

0.02mA - 5.00 mA ± 1% ±5 Counts 0.01mA 0.02mA-5.00mA IEC/EN 60990 Fig 4 (IEC/EN 60990 Fig 3 or Fig 5 Upon Request)

For orders or enquiries call 813-886-2775

Seaward Group USA 6304 Benjamin Road Suite 506 Tampa, FL 33634

Tel: 813-886-2775 Fax: 813-886-2754 Email: sales@seaward-groupusa.com Web: www.seaward-groupusa.com

Also available

ClareHAL 103

AC/DC Hipot (flash dielectric strength) and DC Insulation and Ground/Earth Bond Tester Part No: H103

ClareHAL 102

AC/DC Hipot and DC Insulation Tester with built-in scanner switching matrix Part No: H102

ClareHAL 101

AC/DC Hipot and DC Insulation Tester Part No: H101

ClareHAL 100

40A Ground/Earth Bond Tester Part No: H100

ClareHAL 104 Part No: H104

Information contained within this document is for guidance only - we accept no responsibility for any claim arising from this information