

High-accuracy measurement

ME15W	Directly wired	External power supply + connection cord			Conversion cable	
CT6862-05			<p>CT9555, CT9556 Connects one sensor</p> <p>CT9557* Connects four sensors.</p> <p>L9217 Isolated BNC</p> <p>9165 metallic BNC</p> <p>Connects CT9555, CT9556 or CT6557 and instrument.</p>			<p>CT9901 Converts ME15W terminal to PL23 terminal</p>
CT6872						
CT6872-01						
CT6863-05						
CT6873						
CT6873-01						
CT6875A						
CT6875A-1						
CT6904A						
CT6904A-1						
CT6904A-2						
CT6904A-3						
CT6876A						
CT6876A-1						
CT6877A						
CT6877A-1						
9272-05						
CT6841-05						
CT6843-05						
CT6844-05						
CT6845-05						
CT6846-05						
PW9100A-3						
PW9100A-4						

ME15W	BNC	BNC	BNC	PL23
PW8001	PW3335-03	U8975	MR8870	<p>8971+9318</p> <p>The 9318 comes with the 8971</p>
PW6001	PW3335-04	U8976	MR8880	
PW3390	PW3336	U8978	MR8875 + MR8901	
U8977	PW3337	8966		
		8968		
		8972		

CT9902 (ME15W-ME15W)

The CT9902 can be used to extend a current sensor's cable by 5 m. Up two of these cables can be used for a maximum extension of 10 m.

*When using the CT9902, an addition must be made to accuracy. For details, see the sensor's user manual.

*The CT9557 can output four channels of input as an added waveform.

CT9557 Front

CT9557 Rear

Sensor input **1 2 3**

1	Total RMS output (BNC)	CONNECTION CABLE L9217, 9165 BNC-BNC
2	Total waveform output (BNC)	CONNECTION CABLE L9217, 9165 BNC-BNC
3	Total waveform output (ME15W)	CONNECTION CABLE CT9904 ME15W-ME15W

We accept special orders for extending sensor cables. For inquiries, please contact Hioki for more information.