




1-2 Door Robe / Combi Robe Assembly Guide




1 Dr Robe



2 Dr Robe



1 Dr Combi Robe



2 Dr Combi Robe





BEFORE YOU START

THIS PRODUCT MUST BE SECURED TO THE WALL

INSTALLATION SHOULD BE PERFORMED BY A COMPETENT PERSON ONLY.


THIS PRODUCT COULD BE DANGEROUS IF INCORRECTLY INSTALLED



CONTENTS

4	Robe panels
5	Components
6-12	Robe Assembly
13	Leg Attachment
14	Sliding Robe Leg Attachment
15	Hinge Plate Locations
16	Secure Robe To Wall & Adjacent Units
17-18	Internal Layout Options
19	Hanging Rail Locations
20-21	Internal Drawer Installation
22	Combi Robe Secure Unit To Wall
23	Divider Panel Installation
24	Divider Panel Hanging Rail
25	Hinge Adjustment
26	Loose Shelf Fitting


1-2 Door Robe / Combi Robe Assembly Guide



**RAILS PROVIDED WITH THIS ROBE MAY DIFFER
IN COLOUR TO THE REST OF THE ROBE**

See Pages 17-18 for hanging rail / loose shelf layouts


1-2 Door Robe / Combi Robe Assembly Guide




(F) x20
Wooden
Dowel



(KK) x4
13mm
Screw




(L) x28
15mm
Screw




(K) x12
30mm
Screw




(W) x12
Cam Dowel




(H) x12
Cam Lock




(JJ) x4
Shelf Peg




(N) x6
Door Buffer




(LL) x5
15mm
Cover Cap




(T) x16
Back Panel
Clip




x12
Stick On Cover Cap




x2
Anti Tipping
Bracket




Hinges
Inc Screws



Hinge Mounting Plates
Inc Screws





Robe Legs




**Robe Leg Extension
Packers**

1-2 Door Robe / Combi Robe Assembly Guide




1-2 Door Robe / Combi Robe Assembly Guide




Step 2.

Seat cam dowels **(W)** into holes in both end panels **(B)** as shown.



Do **not** use power tools with cam dowel **(W)** or cam lock **(H)**




1-2 Door Robe / Combi Robe Assembly Guide

Step 3.

Attach panels **(Ct)**, **(Cb)** & **(D)** to panels **(B)**, using cam dowels **(W)**, and dowels **(F)** in positions as shown.



All cam locks **(H)** are to be positioned facing the outside of the robe, for ease of tightening.




1-2 Door Robe / Combi Robe Assembly Guide

Step 4.


Trim the edgeband covering the groove on the bottom of the end panels.

Slide back panel **(A)** into groove of end panels **(B)**.

Once back panel **(A)** is in position, ensure the panel is flush & square with bottom of end panels **(B)**.




1-2 Door Robe / Combi Robe Assembly Guide




Step 5.


Insert cam locks **(H)**. Hand tighten all cam locks **(H)**, this will tighten the robe together.



Do **not** use power tools with cam dowel **(W)** or cam lock **(H)**




1-2 Door Robe / Combi Robe Assembly Guide




Step 6.

Ensure the robe is square. Secure back panel **(A)** with 15mm screws **(L)** equally spaced at the top and bottom of back panel **(A)** into the fixed shelves **(Ct)** and **(Cb)** as shown. Ensure you screw into the centre of fixed shelves **(Ct)** and **(Cb)**. (9mm from the edge).



300 - 600 Widths: 6 x 15mm Screws

800 - 1000 Widths: 12 x 15mm Screws






1-2 Door Robe / Combi Robe Assembly Guide

Step 7.


Secure back panel using 16 x back panel clips **(T)**.

Slide the back panel clips **(T)** into the groove of both end panels **(B)**. The back panel clips **(T)** should be evenly spaced as shown. Once in place, tighten screw.



For adjustable and stable corner robes
please refer to fitting pack Instruction
FI.PK.BED.111.009 or FI.PK.BED.111.010
in your Adj/Stable corner pack for following steps

1-2 Door Robe / Combi Robe Assembly Guide



Step 8.

Position top section of legs as shown. Ensure legs are rotated towards the end panels **(B)**. Secure with 2 x 15mm screws per leg.



Attach bottom section of legs and set all legs to the same height.

300 - 600 Widths: 4 Legs


800 - 1000 Widths: 5 Legs

FOR SLIDING ROBE LEGS PLEASE SEE PAGE 14

For floor to ceiling
sliding doors use
these legs.




It is **important** to lift the robe onto its legs. Do not tilt as depicted in image.




Step 9.

Lift the robe upright. Once in situ level accordingly, using an 8mm hex key from inside the robe. Attach leg packers to one side of the robe to level the robe on uneven surfaces. Cover leg holes with 15mm cover caps **(LL)**.



1-2 Door Robe / Combi Robe Assembly Guide



Standard Legs


Sliding Robe Specific

Step 10.


The rear 2 legs (+ extra 5th leg if required) will use the existing leg positions.
Position the 2 front legs as shown. Ensure legs are rotated towards the end panels **(B)**. Secure all legs with 4 x 15mm screws and adjust all legs to 105mm.

300 - 600 Widths: 4 Legs



800 - 1000 Widths: 5 Legs



Front 2 Legs



5th Leg Placement




It is **important** to lift the robe onto its legs. Do not tilt as depicted in image.



Step 11.

Lift the robe upright. Once in situ level accordingly.
Cover leg holes with 15mm cover caps **(LL)**.


1-2 Door Robe / Combi Robe Assembly Guide




Step 12. (Where Required)
Attach hinge plates onto end panels **(B)** to suit as shown using 2 screws already in hinge plates.

Hinge side to be mounted in accordance to customer specific bedroom plan.

2100 Robe



1380 Combi Robe



1-2 Door Robe / Combi Robe Assembly Guide




Screws for fixing to walls are not provided as these vary depending on wall material and construction. Ensure appropriate fixings for wall constructions are used.

Step 13.

Ensure the robe is level and positioned correctly.

Wren recommends securing the robe to the wall using rails **(D)**. Drill pilot holes through back panel **(A)** and rails **(D)** into the wall. Screw through the pilot holes into the wall, place cover stickers on the heads to conceal them. If unable to use the rails **(D)** to secure the robe to the wall use the anti tipping brackets provided. Attach the brackets to the top of the robe using 15mm screws **(L)** provided. Screw through the brackets into the wall.




Step 14.

Screw into any adjacent robes using 30mm screws **(K)** provided to secure the robe. Screw just to the rear of the hinge plates at the top, middle and bottom on both sides. Place stick on cover caps on the heads to conceal them.




SEE PAGE 22 FOR FIXING COMBI ROBES TO THE WALL




1-2 Door Robe / Combi Robe Assembly Guide

ROBE INTERNAL LAYOUT OPTIONS

- | | |
|--|---|
| 1. 1-2 Door, 1 Shelf and 1 Rail | 4. 1-2 Door, 7 Shelves |
| 2. 1-2 Door, 1 Shelf and 2 Rails | 5. 1-2 Door, 1 Rail, 2 Internal Drawers |
| 3. 1-2 Door, 4 Shelves and 1 Rail | 6. 1-2 Door, 4 Shelves, 2 Internal Drawers |




- | | |
|---|--|
| 7. 1-2 Door, 1 Rail, 3 Internal Drawers | 10. 1-2 Door, 4 Shelves, 4 Internal Drawers |
| 8. 1-2 Door, 4 Shelves; 3 Internal Drawers | 11. 1-2 Door, 1 Rail, 5 Internal Drawers |
| 9. 1-2 Door, 1 Rail, 4 Internal Drawers | 12. 1-2 Door, 4 Shelves; 5 Internal Drawers |




COMBI ROBE INTERNAL LAYOUT OPTIONS

- 15.** 1-2 Door, 1 Rail, 3 Drawers
- 16.** 1-2 Door, 4 Shelves, 3 Drawers
- 17.** 1-2 Door, 1 Rail, 4 Drawers
- 18.** 1-2 Door, 4 Shelves, 4 Drawers





ROBE WITH DIVIDER INTERNAL LAYOUT OPTIONS

- 19.** 2 Door, 1 Rail and 6 Shelves
- 20.** 2 Door, 2 Rails and Internal Drawers
- 21.** 2 Door, 2 Rails and 4 Shelves
- 22.** 2 Door, 1 Rail, 4 Shelves and Internal Drawers




1-2 Door Robe / Combi Robe Assembly Guide

 <i>Infinity</i>	Hanging Rails. Attach hanging rail plates onto end panels (B) as shown using 2 x 15mm screws (L) provided per hanging rail plate. Using the measurements below screw the hanging rail plate onto the end panel using the top hole. Ensure the hanging plate is straight and screw into the bottom hole. Hanging rail plates to be mounted in accordance with customer specific bedroom plan.	 <i>Infinity Plus</i>
--	--	---

Hanging Rail options

- 1 x Hanging Rail **(1)**
- 1 x Hanging Rail + 1 x Shelf **(2)**
- 2 x Hanging Rails + 1 Shelf **(1+3)**



1-2 Door Robe / Combi Robe Assembly Guide





Ensure decor end panels are installed before fitting internal drawer unit.

Internal Drawers.


A. Insert the internal drawer unit into the robe unit. Align the back of the drawers with the back of the robe unit, ensuring the drawer unit is centred inside the robe unit.

B. Position the provided filler panel between the robe and drawer unit, set 5mm back from the front of the drawer unit.



1-2 Door Robe / Combi Robe Assembly Guide

- C.** Screw through drawer end panel, into the filler panel using 2 x 30mm screws **(K)**. Repeat on opposite side.
- D.** Screw down through the drawer unit fixed shelf into the Robe fixed shelf using 4 x 30mm screws **(K)**.
- E.** Position loose shelf on top of drawer unit and screw up through drawer unit top shelf using 4 x 30mm screws **(K)** into loose shelf to secure in place.



1-2 Door Robe / Combi Robe Assembly Guide



Screws for fixing to walls are not provided as these vary depending on wall material and construction. Ensure appropriate fixings for wall constructions are used.


Combi Robe

A. Ensure the combi chest unit is level and positioned correctly. Drill pilot holes through back panel and rail into the wall. Secure chest to the wall by screwing through the pilot holes into the wall.

B. Position the combi robe top section on top of the chest. Align the robe and chest sections so the sides and front are straight and flush. Screw up through the chest units top fixed shelf into the robes bottom fixed shelf using 4 x 30mm screws (**K**).

C. Drill pilot holes through back panel and rails of the top section into the wall. Secure combi robe to the wall.

If unable to use the rails to secure the unit to the wall use the anti tipping brackets provided. Attach the bracket to the top of the robe using 15mm screws (**L**) provided. Screw through the bracket into the wall.



1-2 Door Robe / Combi Robe Assembly Guide

Divider Panel

On the top and bottom fixed shelves mark a line from the inside face of the end panel.

800 Robe: **364mm**, 1000 Robe: **464mm**.

On the marked line secure 2 x fixing blocks to each shelf using 2 x 15mm screws (**L**) per fixing block. (See Fig 1.)
Position the divider panel against the fixing blocks, ensure the shelf drilling is facing the correct direction and secure the divider panel to the fixing blocks using 2 x 15mm screws (**L**) per fixing block. (See Fig 2.)




Fig 1.

Marked Line
Width






Fig 2.



1-2 Door Robe / Combi Robe Assembly Guide

Hanging Rail

See Page 19 for Hanging Rail Locations.

Measure the distance between the hanging plates where the rail will sit (*see Fig 3*).

Cut to size using an appropriate tool and smooth off any sharp edges.

Position the rail on the hanging plates.

Cut rail to size.






Fig 3.

Infinity
Measure between hanging plates

Infinity Plus
Measure between hanging plates







Infinity






Infinity Plus

1-2 Door Robe / Combi Robe Assembly Guide

Hinge Attachment and Adjustment

	Step 1. Insert hinges into frontal hinge holes provided, secure hinges with the 2 x screws and hinge dowels already located in the hinges.  <i>Hinge dowels</i>	
	 CLICK	Step 2. Attach the door to unit, clip hinges onto hinge plates and click to secure.
Step 3. Adjust hinges to suit, using the highlighted screw(s) shown.		



	Step 4. Fit cover caps to hinges and adjust soft-close to suit.	
--	---	---



The top and bottom hinges **MUST** be adjusted to the **SAME STRENGTH**.


Loose Shelves

Secure shelf peg (JJ) to end panels (B) using 1 x 13mm screw (KK) per shelf peg.

4 x shelf pegs (JJ) are required per loose shelf.

Position loose shelf onto shelf pegs (JJ) ensuring the spikes on the shelf pegs locate in the holes on the bottom of the loose shelf.




See customer specific bedroom plan for position and number of loose shelves.



Shelf Peg



13mm Screw





wren