


Units Parts



Tools Required




Remember to take care when unpacking. Please keep your workspace clean, clear and tidy when working. This will help keep all items safe from any damages. Any un-needed cardboard or plastic should be flattened down and placed in the bin.

A minimum of two people will be needed to lift the unit.

Removing the fixtures and fittings


Remove the bin from inside the unit. Pull the door out and lift the bin out.

Take all fixtures and fitting out of the cabinet. All fixtures and fittings should be kept on a clean and level surface and grouped by product.





Taping the frontal

Add low adhesive masking tape to the front of the unit over the frontal. This is to secure the bin mechanism from moving while fitting the unit.




Positioning the leg brackets

Locate the leg brackets and position, as shown in the diagram. Ensure the leg brackets are rotated so the flange covers the outer edge, as this provides support for the edge of the unit.



Fixing the leg bases


Secure each of the leg brackets into place with **4x15mm** screws per bracket.



Inserting the legs

Push each leg firmly down into the leg bracket. Adjusting each leg to **165mm**.


Adjust the legs to the correct height by turning clockwise or anti-clockwise.



Notching out the side panels (when required)

In order to allow for any horizontal pipework running behind the unit, some units will require the back of unit's side to be notched out.

Create a notch for the horizontal pipes at the back of the end panels using a jigsaw.




Lifting the unit into place

When lifting the unit into place do **not** tilt as this can damage the legs.

Place the unit against the wall and align it with the wall markings that will have been drawn during the room preparation stage.

Use a spirit level to ensure the unit is level from front to back, left to right, and diagonally. Adjust the legs if required.

The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



No screws or wall plugs are provided for attaching the unit to the wall.
This is due to variations in wall construction.

Before drilling into the wall you MUST check for any hidden services or pipework within the walls.

Drilling the pilot holes


Drill a pilot hole through the back panel making sure to lightly mark the wall to indicate where the wall fixing should be placed. The hole should be located as per the diagram, in the centre and close to the top of the unit.

For guidance on the appropriate wall fixing for each wall type, please consult the **"Room Preparation Guide."**

Once complete lift and move the unit away from the wall.

Using the pilot hole, drill a hole to suit the fixing. Place the wall fixing within the hole.

Lift and reposition the unit, ensuring it is level and in line with the wall markings.




Inserting the space plug

Position the space plug between the wall and the back of the unit, where the hole is located.

Unwind until the space plug touches both the back panel of the unit and the wall.

Insert the screws into the drilled hole and tighten to the wall.




Before attaching the units together, ensure that the milano/linea profie cutout of both units align.

Securing to adjacent units

Clamp together the two units, checking the front edges are level and flush.

Using the screws provided, **1x30mm** screw should be fixed into each corner of the carcase side.

The screws can be concealed by placing them behind the shelf or behind the hinge plates. The cover caps can be used to hide any visible screw heads that remain.



Adjusting the frontal


To adjust the hinges, use a screwdriver as required at points 1,2 and 3.

Point 1 - Will secure the frontal in place.

Point 2 - Will adjust the height of the frontal. Loosen screw at point 1 and turn screw at point 2. To raise the door turn screw point 2 clockwise, to lower it turn it anti-clockwise.


Point 3 - Will adjust the angle between the frontal and the unit vertically.

Loosen screw at point 1 to tilt the top of the door outwards turn screw at point 3 clockwise. To tilt the door inwards turn screw 2 anti-clockwise (repeat evenly on both sides of the door).




Placing the bin into position

Position the bin back into position within the unit.




Adding the door buffers

Remove the masking tape and position **1x** door buffer at the top and bottom corners of the carcase, as illustrated in the image.



Cleaning the unit

Finally, the unit should be thoroughly cleaned with a vacuum or dust pan and brush to remove any debris that may have accumulated during the installation.



Store the plinth clips and the remaining 15mm screws.
These will be used later when attaching the plinth.

Store the L-brackets.
These will be used later when installing the worktop (laminate or timber).