



Tower Unit


600 Broom Tower (Door, Solid Top, 5 Legs) - Fitting Guide




Unit Parts




30x
15mm Screws




6x
30mm Screws




5x
Legs



5x
Leg Brackets



2x
Plinth Clips



3x
Shelves




12x
Shelf Pegs



2x
Door Buffers




32x
Cover Caps



2x
L Brackets

Tools Required



Drill



Jigsaw



Mallet




Screwdriver



Clamp



Spirit Level



Tape Measure


Remember to take care when unpacking. Please keep your workspace clean, clear and tidy when working. This will help keep all items safe from any damage. Any waste cardboard or plastic should be flattened down and placed in the bin.

A minimum of two people will be needed to lift the unit.

Removing the frontal/s


Before installing the unit, remove the frontal/s by pulling the release catch.

Place the frontal/s in the door safe along their longest length.





Removing the fixtures and fittings

Remove all fixtures and fittings from the unit and keep on a clean and level surface, grouped by product. Place any loose shelves in the door safe along their longest length.




Positioning the leg brackets

Locate the leg brackets and position, as shown in the diagram. Ensure the leg brackets are rotated so the flange covers the outer edge, as this provides support for the edge of the unit.



Fixing the leg brackets


Secure each of the leg brackets into place with **4x15mm** screws per bracket.



Inserting the legs


Push each leg firmly down into the leg bracket. Adjusting each leg to **165mm**.

Adjust the legs to the correct height by turning clockwise or anti-clockwise.



Securing the L-bracket


Secure each of the L-brackets to the rear of the unit using **2x15mm** screws at each side.



Notching out the side panels (when required)

In order to allow for any horizontal pipework running behind the unit, some units will require the back of unit's side to be notched out.

Create a notch for the horizontal pipes at the back of the end panels using a jigsaw.




Lifting the unit into place

When lifting the unit into place do **not** tilt as this can damage the legs.

Place the unit against the wall and align it with the wall markings that will have been drawn during the room preparation stage.

Use a spirit level to ensure the unit is level from front to back, left to right, and diagonally. Adjust the legs if required.

The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.




No screws are provided for attaching the unit to the wall.
This is due to variations in wall construction.

Before drilling into the wall you **MUST** check for any hidden services or pipework within the walls.

Attaching the tower unit to the wall

Fix the unit to the wall through the L-brackets as shown in the image (these fixings are not provided).



To attach adjacent tower units to this unit, refer to:
Milano Mid Profile - Fitting Guide.


To attach adjacent base or wall units to this unit, refer to:
Milano End Profile - Fitting Guide.

Placing the shelves into position

Position the shelf pegs into the pre-drilled holes on the left side of the unit.


Place the shelves into position onto the top of the shelf pegs.

The shelves will touch the back panel when installed, if there is a gap between the back panel and shelf then the shelf has been installed back to front and the shelf needs to be rotated.



Attaching the frontal


The frontal should be re-attached to the unit by clipping the hinges onto the hinge plates. The bar of the hinge needs to be positioned into the hooks on the hinge plate. Then the rear of the hinge pushed to the hinge plate until it clicks.



Joining the frontals (if required)


Align the doors to join together using **2x** fixing plates to the back of both frontals. Ensure a **4mm** gap is maintained between each frontal.

Screw in place using **4x15mm** screws per fixing plate.




Adding the door buffers

Position **1x** door buffer at the top and bottom corners of the unit, as illustrated in the image.



Cleaning the unit

Finally, the unit should be thoroughly cleaned to remove any debris that may have accumulated during the installation.



Store the plinth clips and the remaining 15mm screws.
These will be used later when attaching the plinth.

For door alignment please review the following installation guide:
Door - Door Frontal Hinge Adjustment