

#### **MILANO**



# Feature Unit

# 800 - 1000mm Open Crate Base (Drawer, Open Top, 5 Legs) - Fitting Guide







Remember to take care when unpacking. Please keep your workspace clean, clear and tidy when working. This will help keep all items safe from any damages.


Any waste cardboard or plastic should be flattened down and placed in the bin.

A minimum of two people will be needed to lift the unit.

### Removing the drawer, fixtures and fittings

Remove all fixtures and fittings from the drawer and keep on a clean and level surface and grouped by product.


Before installing the unit, remove all drawers. This is done by pulling the drawer all the way out, and then pulling the front of the drawer upwards.




Place the drawers on top of a piece of leftover cardboard to protect them from damage.

### Positioning the leg brackets

Locate the leg brackets and position, as shown in the diagram. Ensure the leg brackets are rotated so the flange covers the outer edge, as this provides support for the edge of the unit.






### Fixing the leg brackets

Secure each of the leg brackets into place with **4x15mm** screws per bracket.






### Inserting the legs

Push each leg firmly down into the leg bracket. Adjusting each leg to **165mm**.


Adjust the legs to the correct height by turning clockwise or anti-clockwise.



### **Securing the L-bracket**

Secure each of the L-brackets to the upper rear of the unit using **2x15mm** screws at each side.






# Notching out the side panels (when required)

In order to allow for any horizontal pipework running behind the unit, some units will require the back of unit's side to be notched out.

Create a notch for the horizontal pipes at the back of the end panels using a jigsaw.




### Lifting the unit into place

When lifting the unit into place do **not** tilt as this can damage the legs.

Place the unit against the wall and align it with the wall markings that will have been drawn during the room preparation stage.

Use a spirit level to ensure the unit is level from front to back, left to right, and diagonally. Adjust the legs if required.

The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



No screws are provided for attaching the unit to the wall.

This is due to variations in wall construction.


Before drilling into the wall you MUST check for any hidden services or pipework within the walls.

### Attaching the tower unit to the wall

Fix the unit to the wall through the L-brackets as shown in the image (these fixings are not provided).

For guidance on the appropriate wall fixing for each wall type, please consult the "Room Preparation Guide."






### Securing to adjacent units

Clamp together the two units, checking the front edges are level and flush.

Using the screws provided, **1x30mm** screw should be fixed into each corner of the carcase side

The screws can be concealed by placing them behind the shelf or behind the hinge plates or behind the drawer runners. The cover caps can be used to hide any visible screw heads that remain.






# Inserting the drawers

Slide the drawer onto the runners, make sure the runner mechanism and the drawer sides' groove line up.

Push the drawer back into the unit after it has been positioned on the runners; you should hear a click.




### Removing the drawer frontal (If required)


Use the fixing clips, which are found under the drawer's front, to remove the drawer frontal.

**Step 1** - Locate the fixing clips underneath the front of the drawer. Press both clips backwards to release the frontal.

**Step 2** - While holding the clips in the released position, gently pull the frontal away from the drawer sides.

**Step 3 (Re-attached the drawer frontal)**- To reattach, press the fastening clips on both sides and align the frontal with the drawer sides. Push firmly until you hear a click, confirming the frontal is securely attached.





View from underside of the drawer.

### Adjusting the drawer frontal height


To adjust the height of the frontal:

**Step 1** - Use a screwdriver to loosen the top screws on both sides inside the drawer box.

**Step 2** - Adjust the height by turning the lower screw on either the left or right side, depending on the direction required.


**Step 3** - Once the frontal is at the correct height, re-tighten the top screws to lock it in place.

**Step 4** - Finally, press the supplied cover caps onto the adjustment screw heads.



## Cleaning the unit

Finally, the unit should be thoroughly cleaned to remove any debris that may have accumulated during the installation.



Store the plinth clips and the remaining 15mm screws.

These will be used later when attaching the plinth.

