



Tower Cabinet

Pull Out Tower (Door, Solid Top, 4 Legs) - Fitting Guide



Cabinet Parts



8x
1 1/4" Screws



28x
5/8" Screws



18x
Cover Caps




4x
Legs



2x
Toe Kick Clips




2x
L Brackets



5x
Door Buffers


Tools Required



Drill



Stud Finder




Jigsaw



Mallet



Screwdriver



Clamp



Spirit Level



Tape Measure


Remember to take care when unpacking. Please keep your workspace clean, clear, and tidy when working. This will help keep all items safe from damage. Any waste cardboard or plastic should be flattened down and placed in the trash can.

A minimum of two people will be needed to lift the cabinet.

Removing the fittings


Remove all content from the cabinet.

All fittings should be kept on a clean and level surface.



Taping the frontal

Add low adhesive masking tape to the front of the cabinet over the frontal. This is to secure the pull out from moving while fitting the cabinet.




Securing the legs

Secure each of the cabinet legs to the cabinet using **2x 5/8"** screws per leg.


Make sure the legs are positioned as seen in the image to support the end panel.

Set the leg height to **4 9/16"**. The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



Securing the L-brackets

Secure each of the L-brackets to the rear of the cabinet using **2x 5/8"** screws at each side.




Notching out the side panels (when required)

In order to allow for any horizontal pipework running behind the cabinet, some cabinets will require the back of the cabinet's side to be notched out.

Create a notch for the horizontal pipes at the back of the end panels using a jigsaw.


The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



For help on determining the sort of wall you have, please refer to the "Room Preparation Guide."

Locating the stud

Using a stud finder, locate the studs where the cabinet will be installed and mark the wall where the cabinet will sit.




Lifting the cabinet into place

When lifting the cabinet into place, do **not** tilt, as this can damage the legs.

Place the cabinet against the wall and align it with the wall markings that will have been drawn during the room preparation stage.

Use a spirit level to ensure the cabinet is level from front to back, left to right, and diagonally. Adjust the legs if required.

The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.




**No screws are provided for attaching the cabinet to the wall.
This is due to variations in wall construction.**

Before drilling into the wall, you MUST check for any hidden services or pipework within the walls.


Attaching the tower cabinet to the wall

Fix the cabinet to the wall through the L-brackets, as shown in the image (these fixings are not provided).




Securing adjacent cabinets

Any adjacent cabinets need to be secured using the **1 1/4"** screws provided. Screw to the rear of both hinge plates and to the rear of the cabinet at the top and bottom.



Adding the door buffers

Remove the masking tape and position **1x** door buffer at the top and bottom corners of the cabinet, as illustrated in the image.




Images not to scale

Adjusting the frontal


To adjust the frontal, use a screwdriver as required at points 1,2,3,4 and 5.

Point 1 - Will adjust the frontals left and right. Loosen the screws at points 1, reposition the frontal as required then retighten the screws.




Point 2 and 3 - Will adjust the angle between the frontal and the cabinet horizontally.

Loosen the screws at points 2. To rotate the frontal to the right turn the screws at point 3 evenly in opposite directions (right screw clockwise). To rotate the frontal to the left reverse the direction you turn the screwdriver (right screw anti-clockwise). Once in the required position, retighten at point 2.




Point 4 and 5 - Will adjust the frontal up or down and adjust the angle of the frontal vertically.

To adjust frontal up or down, use a screw driver to loosen the screws at points 4, then turn the screws at point 5 clockwise to lower and anti-clockwise to raise the height of the frontal. Then retighten the screws at point 4 to secure in place.



Cleaning the cabinet

Finally, the cabinet should be thoroughly cleaned to remove any debris that may have accumulated during the installation.



Store the toe kick clips and the remaining 5/8" screws.
These will be used later when attaching the toe kick.