



Tower Cabinet

Oven Appliance Tower (Door, Solid Top, 5 Legs) - Fitting Guide

Single Oven



Combi Oven



Cabinet Parts




32x
5/8" Screws



6x
1 1/4" Screws




18x
Cover Caps



5x
Legs



2x
Toe Kick Clips



2x
L-Brackets




2x
Small L-Brackets



5x
Door Buffers




8x
Shelf Pegs



2x
Shelves


Tools Required




Drill




Stud Finder




Jigsaw




Mallet




Screwdriver



Clamp



Spirit Level




Tape Measure

Remember to take care when unpacking. Please keep your workspace clean, clear, and tidy when working. This will help keep all items safe from damage. Any waste cardboard or plastic should be flattened down and placed in the trash can.

A minimum of two people will be needed to lift the cabinet.

Removing the frontals


Before installing the cabinet, remove the frontals by pulling the release catches.



Removing the fittings

Remove all content so the cabinet is empty.

All fittings should be kept on a clean, level surface.




Securing the legs

Secure each of the cabinet legs to the cabinet using **2x 5/8"** screws per leg.


Make sure the legs are positioned as seen in the image to support the end panel.

Set the leg height to **4 9/16"**. The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



Securing the L-bracket


Secure each of the L-brackets to the upper rear of the cabinet using **2x 5/8"** screws at each side.



Notching out the side panels (when required)


In order to allow for any horizontal pipework running behind the cabinet, some cabinets will require the back of cabinets side to be notched out.

Create a notch for the horizontal pipes at the back of the end panels using a jigsaw.



Locating the stud

Using a stud finder, locate the studs where the cabinet will be installed and mark the wall where the cabinet will sit.



For help on determining the sort of wall you have, please refer to the “Room Preparation Guide.”


Lifting the cabinet into place

When lifting the cabinet into place, do not tilt, as this can damage the legs.

Place the cabinet against the wall and align it with the wall markings that will have been drawn during the room preparation stage.

Use a spirit level to ensure the cabinet is level from front to back, left to right, and diagonally. Adjust the legs if required.

The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.




No screws or wall plugs are provided for the wall attachment due to variations in wall materials, thickness, and construction.

Before drilling into the wall, you MUST check for any hidden services or pipework within the walls.

Attaching the cabinet tower to the wall

Fix the cabinet to the wall through the L-brackets, as shown in the image (these fixings are not provided).




To attach adjacent tower units to this unit, refer to:
Milano Mid Profile - Fitting Guide.

To attach adjacent base or wall units to this unit, refer to:
Milano End Profile - Fitting Guide.

Placing the shelf into position (if required)

Place the shelves into position so the pin of each shelf peg is inserted into the pre-drilled holes.


The shelves will touch the back panel when installed, if there is a gap between the back panel and shelf, then the shelf has been installed back to front and the shelf needs to be rotated.



Attaching the frontal

The frontal should be re-attached to the cabinet by clipping the hinges onto the hinge plates.

The bar of the hinge needs to be positioned into the hooks on the hinge plate. Then the rear of the hinge is pushed to the hinge plate until it clicks.



For door alignment please review the following installation guide:
Door- Door Hinge Adjustment

Positioning the appliance


Position the appliance in the tower cabinet, please refer to the manufacturer's guides.



Measuring the gap


Measure the gap between the top of the appliance and the underside of the top door.

Then subtract **1/8"** (gap around the door) from this measurement, subtracting this dimension ensures the gaps remain equal and symmetrical.



Cutting the profile to size


Using a circular saw cut the filler to the required size.



Attaching the profile

Hold the profile against the filler panel and place in position to confirm the size is correct.

Secure the profile to the cut edge of the filler using **5/8"** screws.




Remove the appliance from the tower.

Positioning the filler panel


Hold the filler in place with the profile at the bottom, leaving a **1/8"** gap below the door and ensuring the filler is level.

Lightly mark the back of the filler with a pencil along the underside of the fixed shelf.



Fixing the small L-brackets


Attach **2x** small L-brackets to the rear of the filler panel on the marked line using **2x 5/8"** screws.



Attaching the filler to the tower


Position the filler in place against the tower and secure it using **2x 5/8"** screws.

Make sure to maintain a **1/8"** gap between the door and the profile.



Adding the door buffers

Position **8x** door buffers along the cabinet, as illustrated in the image, and ensure to place them where the door meets the cabinet.



Please consult the manufacturer's installation guide before securing an appliance in the cabinet.


Preparing to secure the appliance

Place masking tape on the face of the profile.

Insert the appliance into the cabinet.

Open the appliance door and use a pencil to mark the location of the screw holes on to the masking tape.


Remove the appliance from the cabinet.



Pre-drilling the profile


Using an appropriately sized bit suitable for metal, drill pilot holes through the profile and into the end panels at the marked locations.

Remove the masking tape.




Securing the appliance

Re-insert the appliance and secure to the cabinet with screws (not provided).



Cleaning the cabinet

Finally, the cabinet should be thoroughly cleaned to remove any debris that may have accumulated during the installation.



Store the toe kick clips and the remaining 5/8" screws.
These will be used later when attaching the toe kick.

For door alignment please review the following installation guide:
Door- Door Hinge Adjustment