



Vanity Tower Cabinet

Tower (Door, Solid Top, 5 Legs) - Fitting Guide



Cabinet Parts



Tools Required




Remember to take care when unpacking. Please keep your workspace clean, clear, and tidy when working. This will help keep all items safe from damage. Any waste cardboard or plastic should be flattened down and placed in the trash can.

A minimum of two people will be needed to lift the cabinet.

Removing the frontal


Before installing the cabinet, the frontal needs to be removed by pulling the release catch.



Removing the fittings

Remove all content so the cabinet is empty.

All fittings and shelves should be kept on a clean and level surface.




Securing the legs

Secure each of the cabinet legs to the cabinet using **2x5/8"** screws per leg.

Make sure the legs are positioned as seen in the image to support the end panel.


Set the leg height to **3"**. The leg height can be adjusted by turning the foot of the leg clockwise or anti-clockwise.



For help on determining the sort of wall you have, please refer to the “Room Preparation Guide.”


Locating the stud

Using a stud finder, locate the studs where the cabinet will be installed and mark the wall where the cabinet will sit.



Checking if the cabinet is level

Before installing the cabinet, hold the cabinet against the wall and check that it is level in multiple places using a spirit level.




Screws and fixings for attaching the cabinet to the wall are not provided, as these vary depending on the wall material and construction. Check that the appropriate fixings for the wall construction are used.

Securing the cabinet


Secure the cabinet in **2** places along the top rail, and **2** places along the bottom rail, where the studs are located.

Use appropriate fixings.



Securing adjacent units

To secure an additional cabinet, screw **2** holes at the front of the cabinet, just behind the hinge plates, and **2** screws at the rear of the cabinet at the top and bottom, using **1 1/4"** screws.




Placing the shelves into position

Position the shelf pegs into the pre-drilled holes.

Place the shelves into position so the pin of each shelf peg is inserted into the pre-drilled holes.


The shelves will touch the back panel when installed, if there is a gap between the back panel and shelf, then the shelf has been installed back to front and the shelf needs to be rotated.



Attaching the frontals (if required)


Align the doors to join together using **2x** fixing plates to the back of both frontals. Ensure a **1/8"** gap is maintained between each frontal.

Screw in place using **4x5/8"** screws per fixing plate.




Attaching the frontal

The frontal should be re-attached to the cabinet by clipping the hinges onto the hinge plates. The bar of the hinge needs to be positioned into the hooks on the hinge plate. Then the rear of the hinge is pushed to the hinge plate until it clicks.




Adding the door buffers

Position **1x** door buffer in the top corner and **1x** door buffer in the bottom corner of the cabinet, as seen in the image.



Cleaning the cabinet

Finally, the cabinet should be thoroughly cleaned to remove any debris that may have accumulated during the installation.



Store the toe kick clips and the remaining 5/8" screws. These will be used later when attaching the toe kick.

For door alignment please review the following installation guide:
Door - Door Hinge Adjustment