


HOLDEN COMMODORE VT - VZ
SEDAN & WAGON 09/97 – 07/06
HOLDEN COMMODORE VU - VZ
UTE 01/01 – 09/07

PART NO.

UNT208

SEDAN

1. Remove floor cover and expose spare wheel.
2. On the driver's side fold back trim to allow access at the rear.
3. Locate the thin body support running vertical.
4. Behind this support and attached $\frac{3}{4}$'s the way up you will find the 6 way tail light connectors.
5. Disconnect these connectors and connect the corresponding Wiring Harness connectors.
6. Located close to but not on the support panel, you will find a 1 way connector taped to the vehicle wiring harness.
7. Connect the 1 way harness from the Towbar Wiring Harness to this connector.
8. Below the rear tail light locate the grommet leading out of the rear of the vehicle.
9. Pierce the grommet to allow the wiring harness to be fed through the grommet and out the rear of the vehicle.
10. Pull the wiring harness through the grommet to meet the required length.
11. Fit the required socket to the wiring harness and mount the plug to the desired position.
12. Using cable ties secure the wiring harness to meet the required length.
13. Replace the floor cover.
14. Test towbar wiring with a trailer testing box.



HOLDEN COMMODORE VT - VZ
SEDAN & WAGON 09/97 – 07/06
HOLDEN COMMODORE VU - VZ
UTE 01/01 – 09/07

PART NO.

UNT208

WAGON

1. Remove the sun shade cover.
2. Remove the floor cover and expose spare wheel.
3. Remove the rear centre trim.
4. Remove the driver's side rear trim. This is in 2 pieces the top plastic cover needs to be removed first.
5. Locate the thin body support running vertical.
6. Behind this support and attached $\frac{3}{4}$'s the way up you will find the 6 way tail light connectors.
7. Located close to but not on the support panel, you will find a 1 way connector taped to the vehicle wiring harness.
8. Locate a grommet as close to rear as possible for the Wiring Harness to exit through.
9. Pierce the grommet to allow the wiring harness to be fed through the grommet and out the rear of the vehicle.
10. Pull the wiring harness through the grommet to meet the required length.
11. Fit the required socket to the wiring harness and mount the plug to the desired position.
12. Using cable ties secure the wiring harness to meet the required length.
13. Replace the driver's side rear trim. This is in 2 pieces the top plastic cover needs to be replaced last.
14. Replace the rear centre trim.
15. Replace the floor cover.
16. Replace the sun shade cover.
17. Test towbar wiring with a trailer testing box.

HOLDEN COMMODORE VT - VZ
SEDAN & WAGON 09/97 – 07/06
HOLDEN COMMODORE VU - VZ
UTE 01/01 – 09/07

PART NO.

UNT208

UTE

1. If the vehicle has a ute liner this may need to be removed or just folded back on the driver's side rear area.
2. On the driver's side rear section locate the access panel and remove the cover.
3. Inside the access panel, locate the thin body support running vertically.
4. Behind this support and attached $\frac{3}{4}$'s the way up you will find the 6 way tail light connectors.
5. Disconnect these connectors and connect the corresponding Wiring Harness connectors.
6. Located close below but not on the support panel, you will find a 1 way connector taped to the vehicle wiring harness.
7. Connect the 1 way harness from the Towbar Wiring Harness to this connector.
8. Running across the underside rear of the vehicle nearer the driver's side, locate the grommet and remove.
9. From inside the access panel feed the Wiring Harness towards the rear of the vehicle and around the corner.
10. From underneath the vehicle where the grommet was removed look for the Wiring Harness. If it is not visible feel around in the hole with a finger.
11. Pierce the grommet to allow the wiring harness to be fed through the grommet and out the rear of the vehicle.
12. Reinsert the grommet and then pull the wiring harness through the grommet to meet the required length.
13. Fit the required socket to the wiring harness and mount the plug to the desired position.
14. Using cable ties secure the wiring harness to meet the required length.
15. Replace the access panel.
16. Replace the ute liner if removed.