

Make / Model TOYOTA COROLLA /HATCH

Other

Year 10/12-ON

### **Part number T2T607**

Maximum towing capacity 1300 kg

Maximum ball load 130 kg

Bar weight 16 kg

Fit with wiring harness part No.EL5540

## Fitting Instructions

### **Warning:**

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

### **General:**

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR TAKING NOTE OF LOCATIONS.
2. REMOVE PLASTIC SHROUDS FROM UNDER VEHICLE. [RETAIN]
  - 2.1. BUMPER CUT TO BE DONE 80MM WIDE X 60MM HIGH FROM BOTTOM CENTRE OF BUMPER.
3. INSTALL TOWBAR USING 6 X M12 BOLTS AND WASHERS INTO EXISTING CAPTIVE NUTS.
  - 3.1. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.
4. TRIM PLASTIC SHROUDS AS TO ALLOW THEM TO BE REFITTED BACK ONTO UNDERSIDE OF VEHICLE.
5. INSTALL BALL MOUNT WITH 2 X M16 BOLTS AND WASHERS PROVIDED AND TIGHTEN.
  - 5.1. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

<b>Metric GRADE 8.8</b>	<b>UNC GRADE 8</b>
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 - 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	

**Torque table for bolt tightening**