Fitting Instructions



SKU

PRODUCT

T2Z734

TAG Standard Duty Towbar for Hyundai i30 (05/2012 - 03/2017)





Scan for latest version of these instructions

SPECIFICATIONS

- Towbar Class: Standard Duty
- · Towing Capacity: 1300kg

IN THIS GUIDE

- · Fitment Instructions
- · Torque Settings
- · Warranty Info



Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.


After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.





Tools Required: Spanners, Sockets, Torque Wrench, Screwdrivers, Trim Removal Tools, Measuring Tape or Ruler, Air Saw or similar

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar	1	7.	M12x1.25 Nut	4
2.	M16x2x40 Bolt	2	8.	Top Plate	1
3.	M16 Spring Washer	2	9.	M12x1.5x50 Bolt	1
4.	M12x1.25x40 Bolt	4	10.	M12x1.5 Nut	1
5.	M12 Flat Washer	9		Compliance Label	1
6.	M12 Shake Proof Washer	5		D-Shackle	1



Step 1. Remove Rear Bumper

Remove Taillights

- 1. Remove rear bumper & crash support panel together then separate these items
- 2. Discard of the crash support panel

Spanners, Sockets, Screwdrivers, trim removal tools

Step 2. Fit Towbar

Fit the towbar to the vehicle:

- 1. Using M12x40 Bolts through the holes in the rear panel secure using 2x Flat washers, and 1x shake proof washer and a M12x1.25 Nut
- 2. Use the M12x50 Bolt along with the top plate, M12x1.5 nut, and 1 of each washer to fasten to the centre support on the underside of the tow hook.

Tighten all hardware to the torque spec indicated

Spanners, Sockets, Torque Wrench

Torque Spec: M12 = 100Nm

Step 3. Perform Bumper Cut

Locate centre of the bumper and cut 150mm each side of the centre up to 40mm above the transition in the bumper where the smooth surface becomes textured.

Please note this is only an indication, bumpers can vary between models and the fitter should take their own measurements.

Measuring Device, Air saw or similar

Step 4. Refit Rear Bumper

Refit the rear bumper and Taillights by reversing actions in Step 1

Spanners, Sockets, Screwdrivers

Step 5. Apply Compliance Sticker to Door Jamb



Apply Towbar info label to the inside of the driver's side door Jamb.





Torque table for bolt tightening

Metric GRADE 8.8	UNC GRADE 8
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 – 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	



TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au