Fitting Instructions



SKU

PRODUCT

T4F444

TAG Heavy Duty Towbar to suit Ford Falcon Cab Chassis (01/1999 - 10/2016)



Example Image Only

Towbars are designed specifically for each vehicle and may differ from the example above



Scan for latest version of these instructions

SPECIFICATIONS

- Towbar Class: Heavy Duty
- · Towing Capacity: 2300kg

IN THIS GUIDE

- · Fitment Instructions
- Torque Settings
- · Warranty Info

Towbar Fitting Instructions





| Item Number | <u>Item</u> | Quantity |
|-------------|-------------------------------------|----------|
| 1 | Towbar – T4F444 | 1 |
| 2 | Ball Mount – L4240 | 1 |
| 3 | M10 x 30 Tap tight | 6 |
| 4 | M12 X 40 X 1.75 Bolt | 2 |
| 5 | ½" Shake proof washer | 8 |
| 6 | Plate with wire & M12 X 1.75 thread | 2 |
| 7 | 3/8" x 1 1/4" UNC Bolt | 2 |
| 8 | 3/8" Shake proof washer | 2 |
| 9 | Plate with wire & 3/8" thread | 2 |
| 10 | 1/2" x 4" UNC Bolt | 6 |
| 11 | ½" UNC Nut | 6 |
| 12 | Plate | 2 |
| 13 | Class 4 Pin & Clip | 1 |

Tools Required: Spanners, Screwdriver, Sockets, Torque wrench

Call 1300 326 134 Version 23.01.2022

Towbar Fitting Instructions



Step-By-Step Instructions

Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owner's Manual.
- This towbar is NOT to be drilled, cut, welded, or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present
- All load ratings shown are under the assumption your trailer has a functional braking system installed
- When installed in positions other than the one depicted in these instructions the Tow Ball Mount
 may interfere or obstruct certain features of your vehicle (tailgate opening, Chassis clearance, etc.)

General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar. (Tray, Canopy, Suspension etc.)
- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.
- The high tensile fasteners supplied with this product are an integral feature to achieving the specified rating, if replacement is required ensure that fasteners of the same grade (8.8) & quality are used. Contact an authorised TAG distributer or the TAG fitment centre (07) 3208 3022 if further information is required.

Towbar Maintenance and Care:

It is recommended, when not in use, the Tow Ball Mount assembly and class 4 Pin and Clip is stored inside the car away from moisture to prevent standing water from forming rust. Inspect to ensure, on regular basis, fasteners are torqued to the specifications below and in good condition.

Ensure that the fitting instructions are read and understood prior to fitment Place these instructions in the vehicle's glovebox after installation is completed

Call 1300 326 134 Version 23.01.2022

Towbar Fitting Instructions



Step 1. Fit Towbar

- a. Remove spare wheel.
- Remove exhaust from three rear most rubber hangers.
- c. Insert 6x ½"x 4" bolts through flat plates and into 3x horizontal holes of each chassis rail.
- d. Lift towbar up to the inside of the chassis rails and push ½"x 4" bolts through to hold tow bar. Fasten loosely with ½" nuts & washers.
- e. Using front most holes in each towbar side arm as guide drill an 11mm hole.
- f. Inset Tapped plate on wire into chassis and align with drilled hole & towbar
- g. Fasten with 3/8" bolts & washers.
- Fasten the underside of towbar to chassis with 6x Taptite bolts.
- i. Tighten all bolts to torque specification on page 2.
- j. Refit exhaust and spare wheel

Step 2. Apply Compliance Label

 Apply one of the compliance labels to the pillar of the driver's door. Leave the remaining label and the fitting instructions in the vehicle handbook



Call 1300 326 134 Version 23.01.2022

Torque table for bolt tightening

| Diameter | Pitch | Grade | Torque | Unit | |
|-------------------------------|-------|-------|--------|------|--|
| M8 | 1.25 | 8.8 | 29 | Nm | |
| M10 | 1.25 | 8.8 | 57 | Nm | |
| M10 | 1.50 | 8.8 | 44 | Nm | |
| M12 | 1.25 | 8.8 | 101 | Nm | |
| M12 | 1.50 | 8.8 | 97 | Nm | |
| M12 | 1.75 | 8.8 | 77 | Nm | |
| M14 | 2.00 | 8.8 | 122 | Nm | |
| M16 | 2.00 | 8.8 | 190 | Nm | |
| Imperial Bolt Torque Settings | | | | | |
| 3/8" | UNC | 8 | 44.75 | Nm | |
| 1/2" | UNC | 8 | 108.5 | Nm | |

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au