



© Panduit Corp. 2013

## INSTALLATION INSTRUCTIONS

IN005

- Position heat shrink over object to be covered without stretching.
- 2) Using a heat gun, infrared heat source, soft yellow flame torch or oven, evenly heat the tubing until it has fully recovered and conforms to object. See package label for shrink temperature.
- 3) Do not char or burn the tubing.

## WARNING!

Follow installation instructions carefully. Use adequate ventilation and avoid charring or burning, Consult Material Safety Data Sheet for further information.

## Special consideration for HSTTPN, Non-Crosslinked PVC Heat Shrink Tubing

- Non-Crosslinked heat shrink is not as shelf stable as crosslinked heat shrink
- Partial tube recovery will occur if the tube is stored at elevated temperatures >70°F (21°C)
- For optimum shelf life, store product at 70°F (21°C); best if used within 12 months of manufacture
- Shelf life may be reduced to one month or less if stored at 95°F (35°C)
- Storing non-crosslinked heat shrink at elevated temperatures, >70°F (21°C), affects the expanded diameter; other tube properties are not affected by elevated storage temperatures

www.panduit.com

E-mail: techsupport@panduit.com Phone: 866-405-6654

For Instructions in Local Languages and Technical Support:

http://www.panduit.com/resources/install\_maintain.asp

Rev 03