



#C2312 Installation Instructions 2011-15 Chevy/GM 2500/3500 HD 4wd Upper Control Arms

Read and understand all instructions and warnings prior to installation of product and operation of vehicle.

Zone Offroad Products recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known. Minimum tool requirements include the following: Assorted metric and standard wrenches, hammer, hydraulic floor jack and a set of jack stands. See the "Special Tools Required" section for additional tools needed to complete this installation properly and safely.

» PRODUCT SAFETY WARNING

Certain Zone Suspension Products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. Zone Offroad Products does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

» TECHNICAL SUPPORT

Live Chat provides instant communication with Zone tech support. Anyone can access live chat through a link on www.zoneoffroad.com.

www.zoneoffroad.com may have additional information about this product including the latest instructions, videos, photos, etc.

Send an e-mail to tech@zoneoffroad.com detailing your issue for a quick response.

888.998.ZONE Call to speak directly with Zone tech support.

» PRE-INSTALLATION NOTES

1. Special literature required: OE Service Manual for model/year of vehicle. Refer to manual for proper disassembly/reassembly procedures of OE and related components.
2. Adhere to recommendations when replacement fasteners, retainers and keepers are called out in the OE manual.
3. Larger rim and tire combinations may increase leverage on suspension, steering, and related components. When selecting combinations larger than OE, consider the additional stress you could be inducing on the OE and related components.
4. Post suspension system vehicles may experience drive line vibrations. Angles may require tuning, slider on shaft may require replacement, shafts may need to be lengthened or trued, and U-joints may need to be replaced.
5. Secure and properly block vehicle prior to installation of Zone Offroad Products. Always wear safety glasses when using power tools.
6. If installation is to be performed without a hoist, Zone Offroad Products recommends rear alterations first.
7. Due to payload options and initial ride height variances, the amount of lift is a base figure. Final ride height dimensions may vary in accordance to original vehicle attitude. Always measure the attitude prior to beginning installation.

Difficulty Level

easy 1 2 **3** 4 5 difficult

Estimated installation: 3-4 hours

Special Tools Required

Torsion Bar Tool - GM #CH48809

Tire/Wheel Fitment

n/a

***Important* Verify you have all of the kit components before beginning installation.**

C2312 Kit Contents

<i>Qty</i>	<i>Part</i>
1	DRV Arm Assembly
1	HD Ball Joint
2	Rubber Bushing
1	Ball Joint Cap
1	Grease Zerk
1	O-ring
1	PASS Arm Assembly
1	HD Ball Joint
2	Rubber Bushing
1	Ball Joint Cap
1	Grease Zerk
1	O-ring

PRE-INSTALLATION NOTES

1. The torsion bars are under extreme pressure and require the use of a Kent Moore #CH48809 torsion bar tool or equivalent for proper unloading/loading. Follow tool manufacturer instructions. The pressure must be taken off the torsion bars to ensure safe disassembly and installation of the control arms.

INSTALLATION INSTRUCTIONS

1. Park vehicle on clean, flat, and level surface. Block the rear wheels for safety.
2. Measure the ride height of the vehicle and record - see side box.
3. Raise the front of the vehicle with a hydraulic jack. Support the frame rails with jackstands. Remove the front wheels.




Figure 1

4. Measure the length of the torsion bar adjuster bolts (top of the adjuster bolt head to adjuster) and record - see side box. **Figure 1**
5. Remove the adjuster bolts, keep driver's and pass side bolts separate.
6. Use the torsion bar removal tool to remove the threaded adjuster assembly. Release the pressure from torsion bar with the unloading tool. **Caution: There is an extreme amount of energy stored in the torsion bars. Use extreme care with the proper tools to avoid serious injury or death.**

Important—measure before starting!

Measure from the center of the wheel up to the bottom edge of the wheel opening

LF _____ RF _____

LR _____ RR _____

Important - Measure from the exposed length of the torsion bar adjusters before starting:

Drv _____ Pass _____

Caution: There is an extreme amount of energy stored in the torsion bars. Use extreme care with the proper tools to avoid serious injury or death.

Upper Control Arm Installation:

7. Remove the upper ball joint nut, reinstall a couple of turns. Hit the side of the knuckle to dislodge the upper ball joint from the steering knuckle. Remove the factory upper control arm from the vehicle. Figure 2a, 2b



Figure 2a




Figure 2b

Note:

02567 part # is stamped in the driver's side arm

02765 is stamped in the passenger's side arm.

Ball joint will be offset towards the rear of the vehicle

Grease the Ball Joint!!!

8. Install new upper control arm assembly with factory cam bolts. Arms are side specific. Snug, but do not tighten at this time. Attach the upper ball joint to the steering knuckle with provided nut, washer, and cotter pin. Tighten the upper ball joint nut to 55 ft-lbs before installing cotter pin. **Figure 3**




Figure 3

9. Reinstall the torsion bar adjusters to the pre-arm installation settings.
10. Reinstall wheels and tighten to factory specifications.
11. Lower the vehicle to the ground. Tighten the upper control arm hardware to 120 ft-lbs.

Post-Installation

1. Check all hardware for proper torque.

Final Check

1. The vehicle will need a complete front end alignment.
2. Check all hardware after 500 miles.

Post-Installation Warnings

1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floor boards and wiring harness. Check steering gear for clearance. Test and inspect brake system.
2. Perform steering sweep to ensure front brake hoses have adequate slack and do not contact any rotating, mobile or heated members. Inspect rear brake hoses at full extension for adequate slack. Failure to perform hose check/ replacement may result in component failure.
3. Perform head light check and adjustment.
4. Re-torque all fasteners after 500 miles. Always inspect fasteners and components during routine servicing.