

Cold-Shot

The Cold-Shot is easy to use. Just place the freeze head around the pipe, attach the hose, and open the cylinder valve. Liquid carbon dioxide will flow into the freeze head and form dry ice with a temperature of minus 110F° (-79C°). That's cold enough to form an ice pack that can withstand 7,000 psi,

yet won't damage pipes.





The freezing times and CO_2 requirements in the table below are general guidelines based on a water temperature 68 F° (20C°). These figures will vary for other temperatures. Longer freezing times are required for plastic pipe.





Cat. No.	Boxed Wt.
CST-2	
Cold-Shot Pipe Freeze Kit	12 lbs.

FREEZE HEAD Size	MATERIAL	FREEZING TIME	FREEZE OPERATIONS PER FREEZE HEAD PER 20 LBS (10 kg) CYLINDER
1/8"	Steel	1 min.	165
(10/12mm)	Copper	1 min.	160
1/4"	Steel	1 min.	130
(15 mm)	Copper	2 min.	75
3/8"	Steel	2 min.	65
(18 mm)	Copper	3 min.	50
1/2"	Steel	3 min.	45
(22 mm)	Copper	5 min.	30
3/4"	Steel	5 min.	29
(28 mm)	Copper	7 min.	22
1"	Steel	7 min.	20
(35 mm)	Copper	10 min.	15
1-1/4"	Steel	11 min.	15
(42 mm)	Copper	14 min.	11
1-1/2"	Steel	16 min.	10
(54 mm)	Copper	24 min.	7
2"	Steel	29 min.	5
(60 mm)	Copper	40 min.	2



/ 1101 Thompson Avenue • McKees Rocks, PA 15136 USA 800-245-6200 or 412-771-6300 • Fax: 412-771-2771 Web Site: www.drainbrain.com

© General Wire Spring Co. 1999 CR-CS-799