






Welcome

Leviton's second-generation Decora Smart Wi-Fi Mini Plug-In Switch makes it easier than ever to control plug-in lamps, electronics, and small appliances. Use your voice with Amazon Alexa, Google Assistant, or Apple Siri—or use a smartphone or tablet for On/Off control with the My Leviton app when you are at home or away.

Built-in scheduling lets you turn devices on or off at specific times and a convenient push button provides manual control. Combine your Mini Plug-In with other Decora Smart Wi-Fi devices to create a Whole Home experience with room scenes and activities to match your lifestyle.





• General purpose loads up to 15 amps, for specific ratings

• Additional self-service support options can be found in

15A. 120VAC. 60Hz

the My Leviton app or at leviton.com/decorasmart.


see the chart below.

LED / CFL / Electronic Ballast


General Use

works with:





- Shows network connectivity.
- Allows you to turn ON/OFF manually.



The size allows two mini plug-ins to be plugged into the same receptacle.



# Getting Started Guide



MINI PLUG-IN SWITCH 2<sup>ND</sup> GEN

Cat. No. D215P

## If you need help...



CHAT www.leviton.com/support

**EMAIL** dssupport@leviton.com

1-800-824-3005 (USA)

Leviton Manufacturing Co., Inc.

DI-000-D215P-02A



## What you need to make it work:

See the complete line of My Leviton<sup>™</sup> app compatible

dimmers, switches, plug-ins, and controllers at

leviton.com/decorasmart

A 2.4GHz Wi-Fi network with high speed internet.

An iOS (12.0 or later) or Android (8.0 or later) NOTE: Make sure Wi-Fi and Bluetooth are enabled on


A My Leviton cloud account (set up through the My Leviton app).

your mobile device.



#### **Quick tip**

You can pair a wireless Anywhere Switch Companion to your Mini Plug-In Switch to create additional locations for control. Learn more at Leviton.com/decorasmart or see the DAWSC Anywhere Switch Companion instructions for connection directions.






## **Installation**

**1.** Insert plug-in switch into any 120VAC receptacle.

**NOTE:** Your Mini Plug-In Switch works with GFCI and AFCI protected receptacles. Do not use in a switched outlet.



2. When device first powers up, the Status LED/button will flash GREEN to show it is ready to be configured.



3. Using a smartphone or tablet, confirm a strong Wi-Fi signal is available in the area in which you are installing your plug-in.





## **Get the app**

To download the app, visit my.leviton.com and select the link or scan the below QR code for your device.



















## **Device setup**

- Decora Smart Wi-Fi 2nd Gen devices can be connected to the My Leviton service, Apple HomeKit, or both.
- For voice control with Amazon Alexa or Google Assistant, setup the device with My Leviton.
- For voice control with Siri, connect your device to Apple HomeKit. See page 12 for instructions on how to add your device to Apple HomeKit.



### Add your device to **My Leviton**



- Make sure the device is in setup mode (States 22) be blinking GREEN). If the status LED is not blinking be blinking on how to put the 1. Make sure the device is in setup mode (status LED should device in setup mode.
- 2. Launch the My Leviton app.
- 3. Log in or choose "Sign Up" for an Account.
- **4.** Follow the instructions on the screen.
- 5. Once logged in tap the "+" in the bottom menu and select "Add Device".
- **6.** Follow the app instructions to add your device and connect it to your home Wi-Fi network.









decorasmartsupport.leviton.com

CALL

1-800-405-5320 (Canada)

201 North Service Road, Melville, NY 11747

© 2021 Leviton Manufacturing Co., Inc. All rights reserved.


Specifications subject to change at any time without notice.







# Plug in your device





## **Test My Leviton** app control

2. Tap icon to turn ON/OFF.







Visit my.leviton.com for a complete list of compatible smart home products.

partners (optional)

**Connect to My Leviton** 





## Add your device to Apple | Limited 2 Year Warranty & **Homekit** (optional)



**NOTE:** Skip step 1 if your device is already enrolled to My Leviton and on your Wi-Fi network.

- 1. Make sure the device is in setup mode (status LED should be blinking GREEN). If the status LED is not blinking GREEN, see page 15 for instructions on how to put the device into
- 2. Using an iOS device, open the Apple Home app and select "Add Accessory".
- 3. Make sure your Decora Smart Wi-Fi Mini Plug-In Switch is model number D215P. Locate and scan the HomeKit setup code on the device or on the front page of this Getting Started Guide.
- **4.** Follow the instructions in the Apple Home app.
- 5. Once the device is set up, you will be able to voice control your Decora Smart Mini Plug-In Switch with Apple Siri.





## What to do if...

#### Your Mini Plug-In Switch is not performing as expected:

- Make sure your plug-in is being supplied from a non-switched 120VAC, 60Hz source ONLY.
- Make sure the lamp or appliance you're controlling is working (local switch is ON) and check for burned-out bulbs.
- Make sure the lamp or appliance you're controlling does not exceed the 15A limit.

#### Not connected to Wi-Fi:


- If your device is setup in the My Leviton app, select your device, then select "Device Settings". On the "Device Settings" screen select "Reconfigure Wireless".
- Follow the prompts to reconfigure your device and update the Wi-Fi settings.

#### How do I clean my device?

• To clean use a damp cloth with mild soap. DO NOT use disinfecting products, including foggers, sprays or other types of atomized cleaning agents.

#### If you need to reset to factory default:

- 1. Press and hold the button.
- 2. After the first 7 seconds it will turn AMBER. Continue holding.
- 3. After 14 seconds, it will quickly flash RED/AMBER. Release button and your plug-in device is reset.



Visit leviton.com/decorasmart or contact our technical support team for additional help.





## **Status LED**

**Quick tip** 

scheduling, remote control, vacation mode.

auto-shutoff, and room scenes.

• The My Leviton app includes many features such as:

Additional self-service support options can be found

in the My Leviton app or at leviton.com/decorasmart.

COLOR	ACTIVITY	STATUS
Green	Flashing	In setup mode and ready to be added to a Wi-Fi network.
Green	Slow Blink	Connecting to a Wi-Fi network on power up.
Green or Off	Solid	Normal operation, can be configured in a setup.
Amber	Slow Blink	Device is not connected to the Wi-Fi network but attempting to reconnect.
Green/ Amber	Alternating Blink	Device is in wireless Anywhere Companion Pairing Mode.
Red	Blink	Wireless Anywhere Companion devices have unpaired or at max number of paired devices.
Green/Red/ Amber	Alternating Blink	Identify feature triggered from the My Leviton app.

Visit My.Leviton.com and select the "Support" option for additional diagnostic assistance.



## **Diagnostic LED**


If your device is not connecting to the My Leviton app, the Status LED can be used as a diagnostic tool. Press the button for at least 2 seconds (but no more than 7 seconds) then release. The Status LED will blink a diagnostic code for 2 seconds.


COLOR	STATUS	
Amber	Not connected to Wi-Fi.	
Red	Connected to Wi-Fi but not able to connect to the My Leviton cloud.	
Green/ Amber, Alternating	Connected to Wi-Fi and My Leviton cloud but unable to set the time from the internet.	
Green	Connected to Wi-Fi and My Leviton cloud is working properly.	



### **Setup mode**

- 1. Hold the button for 7 seconds.
- 2. After the first 7 seconds the status < light will turn AMBER, then release.
- 3. The Status LED will flash GREEN. The device is now in setup mode.







## **Safety first**

WARNING: TO AVOID FIRE, PERSONAL INJURY OR DEATH DO **NOT USE** for the control of high power heating appliances such as portable heaters. There can be unexpected consequences if not used with care. For example, an empty coffee pot can be remotely turned on. If that should happen, your coffee pot could be damaged from overheating. If an electric heater is turned on by remote control while clothing is draped over it, a fire could result. This module will not control lighting that is used with electronic low-voltage and high frequency power supply transformers nor high pressure discharge lamps (HID lighting). This includes mercury-vapor, sodium vapor and metal halide lamps.

- This product is to be installed and/or used in accordance with electrical codes and regulations. Indoor use only.
- If you are unsure about any part of these instructions, consult an electrician.
- · Unplug unit when servicing loads.
- Leviton Wi-Fi enabled devices rely on Wi-Fi communication. For customers looking to install a large number of devices it is recommended to consult the wireless network's access point specifications to determine the maximum number of supported Wi-Fi devices. In some cases, for example large installations, it may be necessary to upgrade to newer high performance wireless grade access points to ensure proper operation.
- Save this instruction sheet. It contains important technical data along with testing and troubles. Troubleshooting information which will be useful after installation is complete.

#### **ADDITIONAL RATINGS:**

- Purpose of control: Operating Control Impulse Voltage: 2500V
- Action Control Type: 1
- Pollution Degree: 2
- Disconnection Type:

Copyright 2021 Leviton Mfg. Co., Inc.

# **Exclusions**

For Leviton's limited product warranty, go to **www.leviton.com.** For a printed copy of the warranty, call 1-800-824-3005.

#### FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at Leviton Manufacturing of Canada ULC to the attention of the Quality Assurance Department, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9 or by telephone at 1 800 405-5320.

#### FCC COMPLIANCE STATEMENT

The enclosed device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (i.) This device may not cause harmful interference (ii.) This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by Leviton could void the user's authority to operate this equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **FCC CAUTION**

Any changes or modifications not expressly approved by Leviton Manufacturing Co., Inc., could void the user's authority to operate the

#### FCC SUPPLIER'S DECLARATION OF CONFORMITY

Model D215P - Wi-Fi Mini Plug-In Switch is manufactured by Leviton Manufacturing Co., Inc. 201 N. Service Road, Melville, NY 11747. www.leviton.com This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **IC STATEMENT**

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### RF EXPOSURE AND CO-LOCATION

To comply with FCC OET Bulletin 65 and ISED RF exposure limits for general population and uncontrolled exposure, this device shall be installed and operated with a minimum distance of 7.9 inches (20 cm) between the radiator and your body. Also, must not be co-located or operated in conjunction with any other antenna or transmitter.

#### Copyright and Trademark Information

Decora and Decora Smart are the registered trademarks of Leviton Manufacturing Co., Inc., registered in the U.S., Canada, Mexico

Google and Google Play are trademarks of Google LLC. Alexa, and related logos are trademarks of Amazon.com, Inc. or its affiliates. Apple®, HomeKit®, and Siri® are trademarks of Apple Inc., registered in the U.S. and other countries. IFTTT and the Wi-Fi CERTIFIED logo are trademarks of their respective owners and any use of such marks by Leviton is under license.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Use herein of other third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement. No part of this document may be reproduced, transmitted or transcribed without the express written permission of Leviton Manufacturing Co., Inc.

