TOGGLE SWITCHES TECHSPAN **SUB-MINI & MINIATURE TOGGLES**



Fig.



Fig. 8



Fig. 9



Fig. 10









Sub-Miniature Toggles

Retail Part No.	Figure No.	Circuit Function			Poles/ Throws	125VAC/ 28VDC	AMPS 250VAC	Actuator Style	Actuator Material	Bushing Length	Mounting Hole	Terminal Type	Hardware	Spec. Drawing Page No.
35-000	1	On		Off	SPST	3A	1.5	Bat	BCP	0.220"	0.195"	Solder	2 N, LR, LW	H–3 A
35-001	2	On		On	SPDT	3A	1.5	Bat	BCP	0.220"	0.195"	Solder	2 N, LR, LW	H–3 A
35-002	3	On		On	DPDT	3A	1.5	Bat	BCP	0.220"	0.195"	Solder	2 N, LR, LW	H–3 A

Miniature Toggles

Retail Part No.	Figure No.	Circuit Function			Poles/ Throws	125VAC/ 28VDC	AMPS 250VAC	Actuator Style	Actuator Material	Bushing Length	Mounting Hole	Terminal Type	Hardware	Spec. Drawing Page No.
35-003	2	On		(0n)	SPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-004	2	On		On	SPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-005	2	On	Off	On	SPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-006	4	On		Off	SPST	5	2	Bat with Boot	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-007	2	On	Off	(0n)	SPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-008	2	(0n)	Off	(0n)	SPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 B
35-009	5	On	On	On	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 C
35-010	6	On		On	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-012	6	On	Off	On	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-014	6	On		(0n)	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-016	6	On	Off	(0n)	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-018	6	(0n)	Off	(0n)	DPDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-024	7	On		On	3PDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 D
35-026	7	On	Off	On	3PDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 D
35-036	8	On		On	4PDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 E
35-038	8	On	Off	On	4PDT	5	2	Bat	BCP	0.350"	0.250"	Solder	2 N, LR, LW	H–3 A
35-053	9	On		On	SPDT	5	2	Flat Lever	Metal	0.364"	0.250"	PCB	2 N, LR, LW	H–3 F
35-057	10	On		On	DPDT	5	2	Flat Lever	Metal	0.364"	0.250"	PCB	2 N, LR, LW	H–3 F
35-059	10	On	Off	On	DPDT	5	2	Flat Lever	Metal	0.364"	0.250"	PCB	2 N, LR, LW	H–3 F
35-070	11	On		On	SPDT	6	3	Paddle	Polyamide	0.452"	0.500"	Solder/QC	N, KN	H–3 G
35-071	11	On	Off	On	SPDT	6	3	Paddle	Polyamide	0.452"	0.500"	Solder/QC	N, KN	H–3 G
35-072	12	On		On	DPDT	6	3	Paddle	Polyamide	0.452"	0.500"	Solder/QC	N, KN	H–3 G
Notes: (On) = Momentary On 3CP = Brass Chrome Plate					KN = Knurled Nut LR = Lock Ring			LW = L N = Nut	PCB = Printed Circuit Board QC = Quick Connect					

Note: All figures are for illustration purpose only, and the number/type of terminals may vary.

All quantities are single unless otherwise noted.

H-2