

Slant/Fin Revital/Line™

Aluminum Baseboard Replacement Cover

Use to Revitalize your aging Hydronic Baseboard up to 8-1/2" Tall by 3" Deep

Before You Order: Measure and Preparation

1. Remove existing baseboard End Caps and Inside Corner Pieces.(figure 1).
2. Measure Front Panel Cover from end to end with a tape measure. (figures 2,3)



Figure 1



Figure 2



Figure 3

**Now you're ready to order your Revital/Line™ replacement covers.
Go [HERE](#) to purchase from our selected distributors.**

3. Remove the old baseboard Front Panel Cover and Damper along with all accessories. (figures 4,5).

4. If the old baseboard length is the same as a standard length Revital/Line™ Cover, then use the standard length Revital/Line™ Cover and End Plates/Solid End Caps. Attach End Plates (if chosen) placing them against the end of the Revital/Line™ Cover and using Phillips Head screws supplied. Use smaller, #4-40 Phillips Head screw at the bottom of Cover, and larger #6 Phillips Head screw (See figure 8) for the top.

All of the other accessories are installed without tools, by placing them over the Revital/Line™ Cover, once in place. When more than one cover is used, the seam between the covers can be hidden by using one of the filler sleeves (2', 4", 7" or 14"). All accessories are sold separately.



Figure 4



Figure 5

From the World's Leader in Baseboard Heaters Since 1949! • www.slantfin.com



5. If the old baseboard heater length is different from a standard length Revital/Line™ Cover, add standard length Revital/Line™ Cover sections together until you get the same length as the old baseboard heater. If you need additional length, you can add 2", 4", 7" and/or 14" filler sleeves. Since the filler sleeves are telescoping, they will fill in less than their dimension size. In addition to the 2", 4", 7" and 14" Filler Sleeves, other accessories such as Flat End Plates, Solid End Caps (Left and Right) and 90 Inside Corners are also available. (figure 6).



Figure 6

6. You may need to loosen the old baseboard from the wall in order to slip the Revital/Line™ Cover behind it, by loosening the screws that hold the old back panel onto the wall. If existing back panel is sealed to wall by paint, seal to wall can be broken with putty knife or similar tool.

If installing with an existing back panel including the heating element you simply use the plastic wall spacers supplied by placing over the element as shown in (Figure 7) For best results use sufficient number of filler sleeves for total length of cover installed based on chart below.




Figure 7

When installing over existing cover without an element, use the metal wall Support Brackets supplied with the Revital/Line™ Cover by sliding brackets into bottom slot (or snapping into place) of Revital/Line™ Cover until it is in the position desired to space the Revital/Line™ Cover from the wall. (See below) for quantities.

Revital/Line™ Cover length, feet	2 to 3-1/2	4 to 5	6 to 8
Plastic Spacers & Support Bracket Quantity	2	3	4

7. When using support Bracket, position new assembled cover with wall brackets below piping, then lift into place so that top lip of new cover goes behind back panel of old baseboard.

Care should be exercised and a piece of wood or other firm but soft material should be used against the Revital/Line™ Cover to make sure that it isn't scratched or damaged while pressing it into place behind old baseboard back panel. Join covers, as described in step 4 above.



Figure 8

8. Attach accessories chosen to Revital/Line™ Cover, as in step 4 above. For added support attach brackets with #10 self-drilling screws provided into the old baseboard back panel using an electric drill with a 5/16" Hex Head Bit. (See Figure 8).