



INSTALLATION INSTRUCTIONS FOR GRAB BARS WITH CONCEALED MOUNTING FLANGE



	Vertical	Horizontal	Diagonal
12"	✓	✗	✗
16"	✓	✓	✗
18"	✓	✓	∠ @ 27°
24"	✓	✗	∠ @ 48°
32"	✓	✗	∠ @ 60°
36"	✓	✗	∠ @ 64°

*Chart is based on 16" centre to centre 1-1/2" width wood wall studs

Vertical

Horizontal

Diagonal

Tools required:

- Stud Finder
- Pencil
- Level
- 1/8" Drill Bit & Drill
- Silicone
- Phillips screwdriver

This box contains:

- Grab Bar (1)
- Screws (6)

Construction:

- Stainless Steel
- Withstands 300 lbs/136 kg pull

PLEASE READ ALL INSTRUCTIONS PRIOR TO STARTING YOUR GRAB BAR INSTALLATION.

1. Determine the desired location for your grab bar. Also, determine the mounting orientation of the grab bar (horizontal, vertical or diagonal) by referencing the chart above.
2. Using a stud finder, locate and mark the location of the studs, noting where the studs begin and end.
3. Slide the decorative flange towards the middle of the bar to expose the mounting flange on both ends.
4. Position the grab bar on the wall in the desired orientation, ensuring that both end flanges are over a stud. Use a level to verify alignment.
5. Mark 3 holes on each side that are directly positioned over the studs.
6. Drill 1/8" holes where the screw hole locations are marked. If the marked screw hole locations are not located at the centre of the stud, drill at an angle such that the drill hole is pointing toward the centre of the stud.
Note: If there is ceramic tile located at marked screw hole location, use a 5/16" carbide tipped drill bit to drill a pilot hole through the tile first in order to prevent cracking the tile.
7. To prevent water seepage, apply a bead of silicone sealer around the edge of the screw hole.
8. Mount the grab bar by screwing all 6 wood screws provided through the grab bar screw holes, and into the newly drilled holes. Tighten.
9. Slide the decorative flanges back and press onto the mounting flange to secure.



- Injury including electrical shock, as well as property damage due to fire or flooding may result if installer drills into electrical wiring or plumbing behind the wall.
- Both end flanges must be firmly secured with screws into wood studs.
- For best results, installation by a qualified professional is recommended.
- Do not install if any components are damaged or missing. Making substitutions or modifying this product in any way will void your warranty. Taymor assumes no liability for any damage or injury caused by improper assembly, installation or use of this product.

Limited Lifetime Warranty

CUSTOMER SERVICE

WEST 1-800-267-4774 | EAST 1-800-387-7064 | taymor.com