

STILETTO INSTALLATION GUIDE

Thank you for choosing Valley Acrylic Bath. This installation manual provides general information on the installation of our products.

All the information in this guide is based upon the most recent product information available at the time of this publication. Valley Acrylic reserves the right to make changes to product characteristics, packaging, or availability at any time without notice.

Thank you for your purchase!

BEFORE YOU BEGIN

- Please read these instructions carefully before beginning your installation.
- Consult your local building codes to ensure that your installation complies with local standards.
- Remove the unit from its packaging. Before disposing, packaging and taking unit from your sales person, inspect the unit to make sure it is in good shape.
- Should inspection reveal any damage or defect in the finish, Contact Us. The warranty does not cover damages or defects in the finish once the unit has been installed. Valley's responsibility for shipping damages ceases upon delivery of the product in good order to the carrier. All complaints regarding damage due to transport must be made directly to the carrier.
- To protect the unit during installation, we suggest that you lay a piece of flat cardboard on the bottom and a moving blanket until you are ready to install it to prevent damage.
- Do not remove the protective polyethylene film from your product until installation is completed to ensure maximum protection from inadvertent damage, except in areas where two surfaces will be in permanent contact.
- Ensure that the floor is level and strong enough to support the weight of the unit.
- If your bathtub is equipped with both a whirlpool and an air system, space must be made for the air system's blower either inside or outside the alcove or island. If the blower cannot be installed under the bathtub, it can be located up to 9 feet away.
- Make sure an access panel - 30" x 15" (750 mm x 400 mm) must be located near the whirlpool pump and/or the air system blower to allow easy servicing.
- Access must be provided for each product component (water heater, light, nozzle, electronic and air control, faucet).
- Whirlpool and/or air systems must be connected before final installation (see the installation and user's guide for whirlpool and air systems).
- Please refer to your product's specification sheet and ensure that both your unit and build plan measure match the stated sizes.



IMPORTANT INFORMATION

The waterfall spout located at the top of the arc should NOT be your main source to fill up the bathtub, you will need a freestanding tub filler to fill it properly. The waterfall spout only allows the water to flow from above, sliding down gracefully and massaging your back and shoulders.

STRUCTURE INSTALLATION

DO NOT build the surrounding structure before receiving your unit. Structure measurements should be verified against the unit to ensure a proper fit.

PLUMBING

Make sure you install all plumbing and drainage before securing the unit. It is always recommended to have a Red Seal certified plumber do the plumbing installations.

Before drilling a hole in the floor for the drainpipe, make sure there are no hidden elements underneath (pipes, floor joists, heating ducts, electrical wires, etc).

LEVELING AND SUPPORT

You should check the leveling of this unit repeatedly during installation to see the best results.

REQUIRED TOOLS


- Measuring Tape
- Pencil
- 3/16" (5mm) and 1/8" (3mm) drill bits
- Hole saw
- Electric drill
- Screwdriver
- Pliers
- Cutting Saw
- Level
- Safety glasses
- Water-resistant glue
- Silicone sealant
- No 8 x 1 1/4" screws (4.2mm x 32mm) Flat or Phillips head
- Mortar

EASY DRAIN INSTALLATION

We recommend our **A10135 EASY DRAIN** (Freestanding bathtub drain)


01

Mark on the wood sub-floor the cutting location for the drain flange.






02

Cut 6-1/2" (16.5mm) hole into the wood sub-floor for the drain flange.




03

Assemble the drain (EASY DRAIN)




04

Screw the drain (EasyDrain) into place.



05

Install the desire tile



BATHTUB INSTALLATION



⚠ TWO (2) PEOPLE REQUIRED ⚠

06

Turn the tub upside down for an easy installation. Ensure you have the correct Waste & Overflow.

Affix the appropriate brass tailpiece to the waste & overflow.

⚠ DO NOT CUT THE SUPPLIED BRASS TAILPIECE, DOING SO MAY CAUSE A LEAK. ⚠




Ensure the measurements between the base of the drain and the P-Trap will accommodate the tailpiece.

⚠ APPLY LUBRICANT TO THE TAILPIECE ⚠


⚠ TWO (2) PEOPLE REQUIRED ⚠

07

Once the tailpiece is been installed on the waste & overflow, position the Tub and tailpiece in-line with the drain.



We recommend our 000.697.000 (Universal Rough-in Valve)




Connect the Stiletto water inlet to the Valve


⚠ TWO (2) PEOPLE REQUIRED ⚠

08

Carefully lower the tub with the installed brass tailpiece as vertical as possible into the drain assembly.



The waterfall spout located at the top of the arc should NOT be your main source to fill up the bathtub, you will need a freestanding tub filler to fill it properly. The waterfall spout only allows the water to flow from above, sliding down gracefully and massaging your back and shoulders.



VALLEY⁺

...you dream it, we create it

Congratulations! You are now a part of the Valley Acrylic family!